

TOOL: xrun 25.03-s001: Started on Sep 16, 2026 at
xrun: 25.03-s001: (c) Copyright 1995-2025 Cadence Design
Top level design units:

tb_CLA

Loading snapshot worklib.tb_CLA:sv
xcelium> source /xcelium25.03/tools/xcelium/files/xmsim
xcelium> run

Time=0 A=0000 B=0000 Cin=0 sum=0000 cout=0
Time=10 A=0000 B=0000 Cin=1 sum=0001 cout=0
Time=20 A=0000 B=0001 Cin=0 sum=0001 cout=0
Time=30 A=0000 B=0001 Cin=1 sum=0010 cout=0
Time=40 A=0000 B=0010 Cin=0 sum=0010 cout=0
Time=50 A=0000 B=0010 Cin=1 sum=0011 cout=0
Time=60 A=0000 B=0011 Cin=0 sum=0011 cout=0
Time=70 A=0000 B=0011 Cin=1 sum=0100 cout=0
Time=80 A=0000 B=0100 Cin=0 sum=0100 cout=0
Time=90 A=0000 B=0100 Cin=1 sum=0101 cout=0
Time=100 A=0000 B=0101 Cin=0 sum=0101 cout=0
Time=110 A=0000 B=0101 Cin=1 sum=0110 cout=0
Time=120 A=0000 B=0110 Cin=0 sum=0110 cout=0
Time=130 A=0000 B=0110 Cin=1 sum=0111 cout=0
Time=140 A=0000 B=0111 Cin=0 sum=0111 cout=0
Time=150 A=0000 B=0111 Cin=1 sum=1000 cout=0
Time=160 A=0000 B=1000 Cin=0 sum=1000 cout=0
Time=170 A=0000 B=1000 Cin=1 sum=1001 cout=0
Time=180 A=0000 B=1001 Cin=0 sum=1001 cout=0
Time=190 A=0000 B=1001 Cin=1 sum=1010 cout=0
Time=200 A=0000 B=1010 Cin=0 sum=1010 cout=0
Time=210 A=0000 B=1010 Cin=1 sum=1011 cout=0
Time=220 A=0000 B=1011 Cin=0 sum=1011 cout=0
Time=230 A=0000 B=1011 Cin=1 sum=1100 cout=0
Time=240 A=0000 B=1100 Cin=0 sum=1100 cout=0
Time=250 A=0000 B=1100 Cin=1 sum=1101 cout=0
Time=260 A=0000 B=1101 Cin=0 sum=1101 cout=0
Time=270 A=0000 B=1101 Cin=1 sum=1110 cout=0
Time=280 A=0000 B=1110 Cin=0 sum=1110 cout=0
Time=290 A=0000 B=1110 Cin=1 sum=1111 cout=0
Time=300 A=0000 B=1111 Cin=0 sum=1111 cout=0
Time=310 A=0000 B=1111 Cin=1 sum=0000 cout=1
Time=320 A=0001 B=0000 Cin=0 sum=0001 cout=0
Time=330 A=0001 B=0000 Cin=1 sum=0010 cout=0
Time=340 A=0001 B=0001 Cin=0 sum=0010 cout=0
Time=350 A=0001 B=0001 Cin=1 sum=0011 cout=0
Time=360 A=0001 B=0010 Cin=0 sum=0011 cout=0

Time=370 A=0001 B=0010 Cin=1 sum=0100 cout=0
Time=380 A=0001 B=0011 Cin=0 sum=0100 cout=0
Time=390 A=0001 B=0011 Cin=1 sum=0101 cout=0
Time=400 A=0001 B=0100 Cin=0 sum=0101 cout=0
Time=410 A=0001 B=0100 Cin=1 sum=0110 cout=0
Time=420 A=0001 B=0101 Cin=0 sum=0110 cout=0
Time=430 A=0001 B=0101 Cin=1 sum=0111 cout=0
Time=440 A=0001 B=0110 Cin=0 sum=0111 cout=0
Time=450 A=0001 B=0110 Cin=1 sum=1000 cout=0
Time=460 A=0001 B=0111 Cin=0 sum=1000 cout=0
Time=470 A=0001 B=0111 Cin=1 sum=1001 cout=0
Time=480 A=0001 B=1000 Cin=0 sum=1001 cout=0
Time=490 A=0001 B=1000 Cin=1 sum=1010 cout=0
Time=500 A=0001 B=1001 Cin=0 sum=1010 cout=0
Time=510 A=0001 B=1001 Cin=1 sum=1011 cout=0
Time=520 A=0001 B=1010 Cin=0 sum=1011 cout=0
Time=530 A=0001 B=1010 Cin=1 sum=1100 cout=0
Time=540 A=0001 B=1011 Cin=0 sum=1100 cout=0
Time=550 A=0001 B=1011 Cin=1 sum=1101 cout=0
Time=560 A=0001 B=1100 Cin=0 sum=1101 cout=0
Time=570 A=0001 B=1100 Cin=1 sum=1110 cout=0
Time=580 A=0001 B=1101 Cin=0 sum=1110 cout=0
Time=590 A=0001 B=1101 Cin=1 sum=1111 cout=0
Time=600 A=0001 B=1110 Cin=0 sum=1111 cout=0
Time=610 A=0001 B=1110 Cin=1 sum=0000 cout=1
Time=620 A=0001 B=1111 Cin=0 sum=0000 cout=1
Time=630 A=0001 B=1111 Cin=1 sum=0001 cout=1
Time=640 A=0010 B=0000 Cin=0 sum=0010 cout=0
Time=650 A=0010 B=0000 Cin=1 sum=0011 cout=0
Time=660 A=0010 B=0001 Cin=0 sum=0011 cout=0
Time=670 A=0010 B=0001 Cin=1 sum=0100 cout=0
Time=680 A=0010 B=0010 Cin=0 sum=0100 cout=0
Time=690 A=0010 B=0010 Cin=1 sum=0101 cout=0
Time=700 A=0010 B=0011 Cin=0 sum=0101 cout=0
Time=710 A=0010 B=0011 Cin=1 sum=0110 cout=0
Time=720 A=0010 B=0100 Cin=0 sum=0110 cout=0
Time=730 A=0010 B=0100 Cin=1 sum=0111 cout=0
Time=740 A=0010 B=0101 Cin=0 sum=0111 cout=0
Time=750 A=0010 B=0101 Cin=1 sum=1000 cout=0
Time=760 A=0010 B=0110 Cin=0 sum=1000 cout=0
Time=770 A=0010 B=0110 Cin=1 sum=1001 cout=0
Time=780 A=0010 B=0111 Cin=0 sum=1001 cout=0
Time=790 A=0010 B=0111 Cin=1 sum=1010 cout=0
Time=800 A=0010 B=1000 Cin=0 sum=1010 cout=0
Time=810 A=0010 B=1000 Cin=1 sum=1011 cout=0