Section 5.1: Bare-Metal Architecture

Bare-metal architecture refers to software that runs directly on hardware without an operating system. The entire application is a single program that initializes hardware and then enters a main loop. This approach is common in simple microcontroller applications where resource constraints make an OS impractical.

Main Loop

The main loop is the heart of a bare-metal application. It typically reads inputs, processes data, and updates outputs in a continuous cycle. The loop must execute fast enough to meet real-time requirements.

Interrupts

Interrupts allow hardware events to preempt the main loop. When an interrupt occurs, the processor saves its current state and jumps to an interrupt service routine (ISR). ISRs should be short and defer complex processing to the main loop.

Cooperative Scheduling

Cooperative scheduling divides the main loop into tasks that voluntarily yield control. Each task runs to completion before the next task starts. This prevents race conditions but requires careful task design.

```
typedef void (*task_t)(void);

task_t tasks[] = {read_sensors, process_data, update_display};
int num_tasks = 3;

while (1) {
    for (int i = 0; i < num_tasks; i++) {
        tasks[i]();
    }
}
```

Preemptive Scheduling

Preemptive scheduling allows the system to interrupt a running task when a higher-priority task is ready. This requires a timer interrupt and a context switch mechanism. It is more complex but provides better responsiveness.

Round-Robin Scheduling

Round-robin scheduling gives each task a fixed time slice in turn. It is fair and simple to implement. However, it may waste time if tasks do not use their full slice.

Priority Scheduling

Priority scheduling assigns each task a priority level. The highest-priority ready task always runs. Lower-priority tasks may starve if high-priority tasks never yield.

Rate-Monotonic Scheduling

Rate-monotonic scheduling assigns priorities based on task periods. Shorter periods get higher priorities. This is optimal for periodic tasks with fixed deadlines.

Earliest Deadline First

Earliest deadline first scheduling dynamically assigns priorities based on deadlines. The task with the nearest deadline runs first. It can achieve higher utilization than rate-monotonic scheduling.

Mutexes

Mutexes protect shared resources from concurrent access. A task must acquire the mutex before using the resource and release it afterward. Failure to release a mutex can cause deadlock.

Semaphores

Semaphores are counters used for signaling between tasks. A binary semaphore acts like a mutex. Counting semaphores can track multiple resources.

Message Queues

Message queues allow tasks to send data to each other. They decouple producers and consumers. Queues can be blocking or non-blocking.

Event Flags

Event flags are bits that tasks can set and wait for. They are lightweight synchronization primitives. Multiple flags can be combined with AND or OR logic.

Memory Pools

Memory pools allocate fixed-size blocks from a pre-allocated region. They avoid fragmentation and are deterministic. Dynamic memory allocation is often forbidden in real-time systems.

Stack Overflow

Stack overflow occurs when a task exceeds its allocated stack space. It can corrupt other memory and cause crashes. Stack canaries and guard pages help detect overflow.

Watchdog Timers

Watchdog timers reset the system if software hangs. The application must periodically kick the watchdog. They are essential for reliability in unattended systems.

Boot Sequence

The boot sequence initializes hardware and loads the application. It may include a bootloader that updates firmware. Secure boot verifies the integrity of the software.

Linker Scripts

Linker scripts control how the compiler places code and data in memory. They define sections for flash, RAM, and special regions. Custom linker scripts are often needed for embedded systems.

Startup Code

Startup code runs before the main function. It sets up the stack pointer, initializes data, and calls constructors. It is usually written in assembly language.

Debugging Techniques

Debugging embedded systems often uses JTAG or SWD interfaces. Printf debugging over UART is also common. Logic analyzers can capture timing issues.

Profiling

Profiling measures where the program spends its time. It helps identify bottlenecks for optimization. Sampling profilers are less intrusive than instrumentation profilers.

Power Management

Power management puts the processor into sleep modes when idle. Wake-up sources include interrupts and timers. Careful design can extend battery life dramatically.

Code Size Optimization

Code size optimization is important for flash-constrained devices. Compiler flags can trade speed for size. Removing unused functions and data helps reduce footprint.

Real-Time Constraints

Real-time constraints specify deadlines for task completion. Hard real-time systems must never miss deadlines. Soft real-time systems can tolerate occasional misses.

Jitter

Jitter is the variation in task execution time. It can affect control loop stability. Minimizing jitter requires predictable code paths.

Latency

Latency is the delay between an event and the response. Interrupt latency includes hardware and software delays. Low latency is critical for responsive systems.

Throughput

Throughput is the amount of work done per unit time. It may be limited by CPU, memory, or I/O. Optimizing throughput often requires balancing trade-offs.

Concurrency

Concurrency allows multiple tasks to make progress. It can be achieved with interrupts or threads. Proper synchronization is essential to avoid bugs.

Deadlock

Deadlock occurs when tasks wait for each other indefinitely. It requires mutual exclusion, hold-and-wait, no preemption, and circular wait. Avoiding any one of these prevents deadlock.

Priority Inversion

Priority inversion happens when a low-priority task holds a resource needed by a high-priority task. A medium-priority task can then preempt the low-priority task. Priority inheritance solves this problem.

Priority Inheritance

Priority inheritance temporarily raises the priority of a task holding a resource. It prevents priority inversion. The task returns to its original priority after releasing the resource.

Priority Ceiling

Priority ceiling assigns each resource a ceiling priority. A task holding the resource runs at that priority. It prevents both priority inversion and deadlock.

Starvation

Starvation occurs when a task never gets enough CPU time. It can happen with priority scheduling. Aging techniques can help prevent starvation.

Fairness

Fairness ensures that all tasks get a reasonable share of CPU time. Round-robin is fair by design. Priority scheduling may sacrifice fairness for responsiveness.

Context Switching

Context switching saves and restores the state of a task. It includes registers, stack pointer, and program counter. The overhead must be minimized for efficient systems.

Interrupt Latency

Interrupt latency is the time from interrupt request to ISR execution. It includes hardware delays and software overhead. Nested interrupts can increase latency.

Nested Interrupts

Nested interrupts allow higher-priority interrupts to preempt lower-priority ISRs. They require careful stack management. Not all processors support nesting.

Interrupt Masking

Interrupt masking disables interrupts during critical sections. It prevents race conditions with ISRs. Masking should be brief to avoid missing events.

Critical Sections

Critical sections are code regions that must not be interrupted. They protect shared data from concurrent access. Entering and exiting them must be atomic.

Atomic Operations

Atomic operations complete without interruption. They are used to implement synchronization primitives. Hardware provides atomic instructions for common operations.

Memory Barriers

Memory barriers prevent reordering of memory operations. They ensure that writes are visible to other processors. They are needed in multi-core systems.

Cache Coherency

Cache coherency ensures that all processors see the same data. It is maintained by hardware protocols. Software must flush caches when using DMA.

DMA

DMA transfers data between memory and peripherals without CPU intervention. It frees the CPU for other tasks. DMA controllers can be programmed with descriptors.

Double Buffering

Double buffering uses two buffers to avoid waiting for I/O. While one buffer is being filled, the other is processed. It is common in audio and video applications.

Ring Buffers

Ring buffers are circular queues for streaming data. They are efficient for producer-consumer scenarios. Overflow and underflow must be handled.

Zero-Copy

Zero-copy techniques avoid copying data between buffers. They reduce CPU overhead and memory bandwidth. They require careful buffer management.

Scatter-Gather

Scatter-gather DMA transfers data to or from multiple buffers. It is useful for network packets. The DMA controller follows a list of descriptors.

Bus Arbitration

Bus arbitration resolves conflicts when multiple masters request the bus. Priority schemes determine which master wins. Fairness can be achieved with round-robin arbitration.

Clock Gating

Clock gating disables the clock to unused peripherals. It reduces power consumption. Software must enable clocks before accessing peripherals.

Voltage Scaling

Voltage scaling reduces the supply voltage when frequency is low. It saves power quadratically. Dynamic voltage and frequency scaling adjusts both together.

Thermal Management

Thermal management prevents overheating by throttling the CPU. It may reduce frequency or shut down peripherals. Temperature sensors provide feedback.

Reliability

Reliability is the probability that a system operates without failure. It is measured by mean time between failures. Redundancy and error detection improve reliability.

Section 5.2: RTOS Basics

A real-time operating system provides services for multitasking, synchronization, and timing. It is more complex than bare-metal but offers better structure for large applications. Popular RTOSes include FreeRTOS, Zephyr, and VxWorks.

Kernel

The kernel is the core of the RTOS. It manages tasks, interrupts, and resources. It runs in privileged mode and provides system calls to applications.

Task Control Block

The task control block stores information about each task. It includes the stack pointer, priority, and state. The kernel uses it to switch between tasks.

Task States

Tasks can be in states such as ready, running, blocked, or suspended. The kernel moves tasks between states based on events. Only one task runs at a time on a single-core processor.

Task Creation

Task creation allocates memory for the stack and TCB. It sets the initial state and priority. Tasks can be created statically or dynamically.

Task Deletion

Task deletion frees the task's resources. It must be done carefully to avoid memory leaks. A task can delete itself or another task.

Task Suspension

Task suspension prevents a task from running. It is useful for debugging or power management. The task remains in memory but is not scheduled.

Task Resumption

Task resumption moves a suspended task back to ready. It can be triggered by another task or an interrupt. The task continues from where it left off.

Idle Task

The idle task runs when no other task is ready. It can put the processor into a low-power mode. It must never block or suspend.

Tick Interrupt

The tick interrupt is a periodic timer interrupt. It drives the RTOS scheduler and timeouts. The tick rate is typically 1 ms to 10 ms.

Delay Functions

Delay functions block a task for a specified time. They are implemented using the tick interrupt. Accuracy depends on the tick rate.

Timeouts

Timeouts allow blocking operations to return after a maximum wait. They prevent tasks from waiting forever. The timeout value is specified in ticks.

Software Timers

Software timers execute a callback after a delay or periodically. They are managed by the RTOS. They run in the context of a timer task.

Event Groups

Event groups are sets of event flags. Tasks can wait for any or all flags in the group. They are useful for complex synchronization.

Notifications

Notifications are lightweight signals between tasks. They are faster than semaphores. Each task has a built-in notification value.

Stream Buffers

Stream buffers are optimized for single-reader, single-writer scenarios. They are faster than message queues. They support variable-length messages.

Message Buffers

Message buffers are built on stream buffers. They preserve message boundaries. They are convenient for packet-based communication.

Memory Allocation

Memory allocation in an RTOS can be static or dynamic. Static allocation is deterministic and preferred for safety-critical systems. Dynamic allocation uses heap_1 to heap_5 schemes in FreeRTOS.

Heap Management

Heap management tracks free memory blocks. Fragmentation can cause allocation failures. Some schemes coalesce adjacent free blocks.

Stack Monitoring

Stack monitoring detects overflow and underflow. It can use canary values or hardware support. The RTOS can report errors to the application.

Run-Time Statistics

Run-time statistics measure CPU usage per task. They help identify bottlenecks. They require a high-resolution timer.

Trace Hooks

Trace hooks allow external tools to monitor RTOS events. They are used for debugging and profiling. They can be enabled or disabled at compile time.

Configuration

RTOS configuration is done through a header file. It sets the tick rate, heap size, and feature flags. Unused features can be disabled to save memory.

Porting

Porting adapts the RTOS to a new hardware platform. It requires implementing context switch and tick interrupt. Most RTOSes provide ports for common architectures.

Portable Layer

The portable layer contains hardware-specific code. It is written in assembly and C. It is separated from the kernel for easy porting.

Kernel Objects

Kernel objects include tasks, queues, semaphores, and timers. They are referenced by handles. The kernel manages their lifecycle.

Handles

Handles are opaque references to kernel objects. They are returned when objects are created. They are passed to API functions.

Error Handling

Error handling checks return values from RTOS functions. It is important for robust systems. Assertions can catch programming errors.

Assertions

Assertions verify that conditions are true at runtime. They help catch bugs early. They can be disabled in production builds.

Logging

Logging records events for later analysis. It can use UART, flash, or network. Log levels control the amount of output.

Watchdog Integration

Watchdog integration kicks the watchdog from a task. It ensures the system is responsive. The watchdog timeout must be longer than the longest task.

Boot Time

Boot time is the time from power-on to application start. It includes hardware initialization and RTOS startup. Fast boot is important for some applications.

Code Size

Code size is the amount of flash memory used. It includes the RTOS and application. Compiler optimization and feature selection reduce it.

RAM Usage

RAM usage includes stacks, heap, and kernel data. It is critical for small devices. Static allocation helps predict it.

Real-Time Performance

Real-time performance is measured by latency and jitter. It depends on the scheduler and hardware. Benchmarks help evaluate it.

Safety Certification

Safety certification requires rigorous testing and documentation. Some RTOSes are certified for IEC 61508 or ISO 26262. Certification is expensive and time-consuming.

Open Source

Open source RTOSes are free to use and modify. They have large communities. Commercial support is available for some.

Commercial RTOS

Commercial RTOSes offer support and certification. They may have better tools and documentation. They are licensed per device or per seat.

Choosing an RTOS

Choosing an RTOS depends on requirements and constraints. Consider footprint, features, and support. Evaluate several options before committing.

Migration

Migration moves an application from bare-metal to RTOS. It requires restructuring the code. The benefits must outweigh the effort.

Best Practices

Best practices include keeping ISRs short and using queues for communication. Avoid blocking in high-priority tasks. Test under worst-case conditions.

Common Pitfalls

Common pitfalls include priority inversion and stack overflow. Forgetting to release mutexes causes deadlock. Using dynamic memory in real-time code is risky.

Debugging RTOS Issues

Debugging RTOS issues requires specialized tools. Thread-aware debuggers show task states. Trace tools visualize scheduling.

Performance Tuning

Performance tuning adjusts task priorities and stack sizes. It uses run-time statistics and profiling. Small changes can have large effects.

Memory Protection

Memory protection prevents tasks from accessing each other's memory. It uses hardware MPU or MMU. It improves reliability and security.

Multi-Core Support

Multi-core support runs the RTOS on multiple processors. It requires synchronization between cores. Not all RTOSes support multi-core.

Symmetric Multiprocessing

Symmetric multiprocessing runs tasks on any core. The scheduler balances load. It is more flexible but harder to debug.

Asymmetric Multiprocessing

Asymmetric multiprocessing dedicates cores to specific tasks. It is simpler to implement. It may waste resources if load is unbalanced.

Inter-Core Communication

Inter-core communication uses shared memory or message passing. It requires careful synchronization. Hardware mailboxes can help.

Load Balancing

Load balancing distributes tasks across cores. It can be static or dynamic. The goal is to maximize throughput.

Affinity

Affinity binds a task to a specific core. It can improve cache performance. It reduces flexibility.

Migration

Migration moves a task between cores. It is expensive due to cache effects. The scheduler may do it to balance load.

Synchronization

Synchronization ensures that cores coordinate their actions. It uses spinlocks or hardware primitives. Deadlock is possible if not careful.

Spinlocks

Spinlocks busy-wait for a lock to be released. They are efficient for short critical sections. They waste CPU time if held long.

Barriers

Barriers make all cores wait until they reach a point. They are used for phase synchronization. They can be implemented with counters.

Atomic Variables

Atomic variables support lock-free operations. They are used for counters and flags. They require hardware support.

Memory Ordering

Memory ordering defines the visibility of memory operations. It is relevant in multi-core systems. Barriers enforce ordering.

Cache Effects

Cache effects can cause unexpected performance. False sharing occurs when cores access different data in the same cache line. Padding can avoid it.

False Sharing

False sharing happens when cores write to different variables in the same cache line. It causes cache invalidations. It can be detected with profiling tools.

Padding

Padding adds unused bytes to align data. It prevents false sharing. It wastes memory.

Alignment

Alignment ensures that data starts at a memory address that is a multiple of its size. It is required by some hardware. It can improve performance.

Endianness

Endianness is the order of bytes in a multi-byte value. It matters when communicating between different processors. Network protocols use big-endian.

Byte Swapping

Byte swapping converts between endianness. It is needed when reading or writing network data. Functions like htonl and ntohl do it.

Bit Manipulation

Bit manipulation is common in embedded code. It is used for flags, masks, and registers. Macros can make it more readable.

Volatile

Volatile tells the compiler that a variable may change unexpectedly. It prevents optimization. It is used for hardware registers and shared variables.

Const

Const marks data that should not be modified. It can be placed in flash memory. It helps catch errors.

Static

Static limits the scope of a variable or function. It is used for private data. It can also affect memory allocation.

Inline

Inline suggests that the compiler should expand a function at the call site. It avoids function call overhead. It increases code size.

Macros

Macros are text substitutions processed by the preprocessor. They are used for constants and simple functions. They can be error-prone.

Function Pointers

Function pointers store the address of a function. They are used for callbacks and dispatch tables. They are common in RTOS APIs.

Callbacks

Callbacks are functions passed to other functions. They are used for asynchronous notifications. They run in the context of the caller.

Dispatch Tables

Dispatch tables map events to handler functions. They are efficient for state machines. They are easy to modify.

State Machines

State machines model behavior as states and transitions. They are common in embedded systems. They can be implemented with switch statements or tables.

Hierarchical State Machines

Hierarchical state machines nest states inside other states. They reduce duplication. They are more complex to implement.

Event-Driven Architecture

Event-driven architecture responds to events rather than polling. It is efficient for sporadic events. It requires an event queue.

Publish-Subscribe

Publish-subscribe decouples producers and consumers. Publishers send messages to topics. Subscribers receive messages from topics.

Observer Pattern

Observer pattern notifies multiple objects of changes. It is similar to publish-subscribe. It is used for UI updates.

Model-View-Controller

Model-view-controller separates data, presentation, and control. It is common in GUI applications. It can be adapted for embedded displays.

Layered Architecture

Layered architecture organizes code into layers. Each layer provides services to the layer above. It promotes modularity.

Hardware Abstraction Layer

Hardware abstraction layer hides hardware details. It provides a portable interface. It is essential for porting.

Board Support Package

Board support package contains code for a specific board. It includes drivers and initialization. It is provided by the hardware vendor.

Device Drivers

Device drivers control peripherals. They handle interrupts and DMA. They expose a simple API.

Interrupt Service Routines

Interrupt service routines handle hardware events. They should be short and fast. They defer work to tasks.

Deferred Processing

Deferred processing moves work from ISRs to tasks. It keeps interrupt latency low. It uses queues or flags.

Bottom Half

Bottom half is the deferred part of interrupt handling. It runs in a task context. It can block and use the RTOS.

Top Half

Top half is the ISR that runs immediately. It acknowledges the hardware and schedules the bottom half. It must be very fast.

Tasklets

Tasklets are small deferred functions. They run in a dedicated task. They are simpler than full tasks.

Work Queues

Work queues are lists of deferred functions. They are processed by a worker task. They are flexible.

Timers

Timers trigger events after a delay. They can be one-shot or periodic. They are managed by the RTOS.

Watchdog

Watchdog resets the system if software hangs. It must be kicked periodically. It is a last line of defense.

Brown-Out Detection

Brown-out detection resets the system when voltage drops. It prevents corruption during power loss. It is configured in hardware.

Power-On Reset

Power-on reset initializes the system at startup. It ensures a clean state. It is triggered by hardware.

External Reset

External reset is triggered by a pin. It allows manual or external reset. It is debounced in hardware.

Software Reset

Software reset restarts the system from software. It is used for updates or recovery. It preserves some state.

Boot Modes

Boot modes select where to load the application from. They include flash, UART, and USB. They are configured by pins or fuses.

Bootloader

Bootloader loads the application into memory. It can update firmware over the network. It is small and reliable.

Secure Boot

Secure boot verifies the signature of the application. It prevents unauthorized code. It uses cryptographic keys.

Firmware Update

Firmware update replaces the application. It must be reliable and recoverable. It is critical for deployed devices.

Over-the-Air Updates

Over-the-air updates use wireless networks. They require security and bandwidth management. They are convenient for users.

Rollback

Rollback reverts to the previous firmware version. It is used when an update fails. It requires storing two versions.

Dual Bank

Dual bank stores two firmware images. It allows safe updates. It doubles flash usage.

Recovery Mode

Recovery mode is a minimal boot mode. It allows repairing a bricked device. It is triggered by a special sequence.

Diagnostics

Diagnostics test hardware and software. They run at boot or on demand. They report errors.

Self-Test

Self-test checks memory, peripherals, and sensors. It is important for safety. It can be run periodically.

Logging

Logging records events for later analysis. It can use flash or network. It is limited by storage.

Telemetry

Telemetry sends data to a remote server. It is used for monitoring. It requires connectivity.

Remote Debugging

Remote debugging connects a debugger over a network. It is useful for deployed devices. It is slow.

Trace

Trace records execution history. It helps debug timing issues. It requires hardware support.

Profiling

Profiling measures where time is spent. It helps optimize code. It can be sampling or instrumentation.

Coverage

Coverage measures which code is executed. It helps find untested paths. It is used in testing.

Unit Testing

Unit testing tests individual functions. It is automated. It is easier on host machines.

Integration Testing

Integration testing tests components together. It is more complex. It is done on target hardware.

Hardware-in-the-Loop

Hardware-in-the-loop simulates sensors and actuators. It tests software without real hardware. It is used for safety-critical systems.

Simulation

Simulation runs software on a host machine. It is fast and easy. It may not match hardware exactly.

Emulation

Emulation runs software on a virtual machine. It is slower than simulation. It can be more accurate.

Virtualization

Virtualization runs multiple operating systems on one hardware. It is used for isolation. It is common in servers.

Containers

Containers isolate applications without a full OS. They are lightweight. They are used for deployment.

Orchestration

Orchestration manages containers across multiple hosts. It is used for scaling. It is common in cloud.

Edge Computing

Edge computing processes data near the source. It reduces latency and bandwidth. It is used for IoT.

Fog Computing

Fog computing is a layer between edge and cloud. It aggregates data from edge devices. It is used for hierarchical systems.

Cloud Integration

Cloud integration connects devices to cloud services. It is used for storage and analytics. It requires security.

Security

Security protects against attacks. It includes encryption, authentication, and access control. It is critical for connected devices.

Encryption

Encryption protects data confidentiality. It uses symmetric or asymmetric algorithms. It is computationally expensive.

Authentication

Authentication verifies identity. It uses passwords, certificates, or tokens. It prevents unauthorized access.

Access Control

Access control limits what users can do. It uses roles and permissions. It is enforced by the system.

Secure Storage

Secure storage protects keys and data. It uses hardware security modules. It is tamper-resistant.

Random Number Generation

Random number generation is needed for cryptography. It must be unpredictable. Hardware sources are preferred.

Side-Channel Attacks

Side-channel attacks exploit physical leakage. They include timing and power analysis. Countermeasures are difficult.

Fault Injection

Fault injection causes errors to test robustness. It is used for security testing. It can be accidental or malicious.

Tamper Detection

Tamper detection senses physical attacks. It triggers zeroization of keys. It is used in high-security devices.

Zeroization

Zeroization erases sensitive data. It is triggered by tamper detection. It must be irreversible.

Secure Boot Chain

Secure boot chain verifies each stage of boot. It starts from a root of trust. It ensures only authorized code runs.

Root of Trust

Root of trust is the foundation of security. It is immutable hardware. It stores keys and verifies boot.

Attestation

Attestation proves the state of the device. It is used for remote verification. It includes measurements of software.

Secure Update

Secure update verifies the signature of new firmware. It prevents malicious updates. It is critical for security.

Vulnerability Management

Vulnerability management tracks and fixes security issues. It includes patching and monitoring. It is ongoing.

Compliance

Compliance meets regulatory requirements. It includes standards like IEC 62443 and ISO 27001. It is documented.

Risk Assessment

Risk assessment identifies threats and vulnerabilities. It evaluates likelihood and impact. It guides security decisions.

Threat Modeling

Threat modeling systematically identifies threats. It uses diagrams and checklists. It is done early in design.

Security Architecture

Security architecture defines security components and their relationships. It includes trust boundaries. It is part of system design.

Defense in Depth

Defense in depth uses multiple layers of security. It assumes any layer can fail. It is a best practice.

Least Privilege

Least privilege grants only necessary permissions. It limits damage from compromise. It is enforced by the system.

Separation of Duties

Separation of duties requires multiple people for critical actions. It prevents fraud. It is used in high-security environments.

Audit Logging

Audit logging records security events. It is used for forensics. It must be tamper-proof.

Incident Response

Incident response handles security breaches. It includes detection, containment, and recovery. It is planned in advance.

Business Continuity

Business continuity ensures operations during disruptions. It includes backups and redundancy. It is part of risk management.

Disaster Recovery

Disaster recovery restores systems after major failures. It includes backups and offsite storage. It is tested regularly.

Backup

Backup copies data for recovery. It is automated. It is stored securely.

Redundancy

Redundancy duplicates components for reliability. It includes hardware and data. It is used in critical systems.

Failover

Failover switches to a backup system. It is automatic or manual. It minimizes downtime.

Load Balancing

Load balancing distributes requests across servers. It improves performance and reliability. It is used in web services.

Clustering

Clustering groups servers for high availability. It shares state or data. It is complex to manage.

Scalability

Scalability handles increasing load. It can be vertical or horizontal. It is planned in architecture.

Elasticity

Elasticity automatically adjusts resources to load. It is used in cloud. It saves cost.

Monitoring

Monitoring tracks system health. It includes metrics and alerts. It is essential for operations.

Alerting

Alerting notifies operators of problems. It is based on thresholds. It must avoid false positives.

Dashboards

Dashboards visualize system status. They show metrics and trends. They are used by operators.

Logging

Logging records events for analysis. It is centralized. It is searchable.

Tracing

Tracing follows requests through systems. It helps debug distributed systems. It is used for performance.

Profiling

Profiling measures resource usage. It helps optimize code. It is done in production.

Capacity Planning

Capacity planning predicts future needs. It uses historical data. It is done regularly.

Cost Optimization

Cost optimization reduces expenses. It includes right-sizing and reserved instances. It is ongoing.

Sustainability

Sustainability reduces environmental impact. It includes energy efficiency and recycling. It is a growing concern.

Ethics

Ethics guides responsible behavior. It includes privacy and fairness. It is part of professional practice.

Privacy

Privacy protects personal data. It is regulated by laws like GDPR. It is a design consideration.

Data Protection

Data protection secures data at rest and in transit. It includes encryption and access control. It is required by law.

Consent

Consent allows users to control their data. It must be informed and explicit. It is required by privacy laws.

Transparency

Transparency explains how data is used. It builds trust. It is required by privacy laws.

Accountability

Accountability assigns responsibility for data handling. It includes audits and documentation. It is required by privacy laws.

Data Minimization

Data minimization collects only necessary data. It reduces risk. It is a privacy principle.

Purpose Limitation

Purpose limitation uses data only for stated purposes. It prevents misuse. It is a privacy principle.

Storage Limitation

Storage limitation deletes data when no longer needed. It reduces risk. It is a privacy principle.

Accuracy

Accuracy ensures data is correct. It is important for decision-making. It is a privacy principle.

Integrity

Integrity protects data from unauthorized modification. It uses checksums and signatures. It is a security principle.

Availability

Availability ensures systems are accessible when needed. It is measured by uptime. It is a security principle.

Confidentiality

Confidentiality protects data from unauthorized access. It uses encryption and access control. It is a security principle.

CIA Triad

CIA triad is confidentiality, integrity, and availability. It is the foundation of security. It guides design.

Non-Repudiation

Non-repudiation prevents denial of actions. It uses digital signatures. It is used in legal contexts.

Authentication

Authentication verifies identity. It uses passwords, certificates, or tokens. It is the first line of defense.

Authorization

Authorization grants permissions. It follows authentication. It is enforced by the system.

Accounting

Accounting tracks resource usage. It is used for billing and auditing. It is part of AAA.

AAA

AAA is authentication, authorization, and accounting. It is a framework for access control. It is used in networks.

Single Sign-On

Single sign-on allows one login for multiple systems. It uses tokens or federation. It is convenient for users.

Federation

Federation connects identity systems. It allows trust between organizations. It is used for SSO.

Tokens

Tokens represent authentication or authorization. They are issued by servers. They are passed by clients.

Certificates

Certificates bind identities to public keys. They are issued by certificate authorities. They are used for TLS.

Public Key Infrastructure

Public key infrastructure manages certificates. It includes CAs and revocation. It is complex to operate.

Certificate Authority

Certificate authority issues certificates. It is trusted by clients. It must be secure.

Revocation

Revocation invalidates certificates. It uses CRLs or OCSP. It is important for security.

Certificate Pinning

Certificate pinning restricts which certificates are accepted. It prevents MITM attacks. It is used in mobile apps.

Mutual TLS

Mutual TLS authenticates both client and server. It uses certificates on both sides. It is used for machine-to-machine.

VPN

VPN creates a secure tunnel over a network. It uses encryption and authentication. It is used for remote access.

Firewall

Firewall filters network traffic. It blocks unauthorized connections. It is a security boundary.

Intrusion Detection

Intrusion detection monitors for attacks. It uses signatures or anomalies. It alerts operators.

Intrusion Prevention

Intrusion prevention blocks attacks. It is inline with traffic. It can cause false positives.

Honeypot

Honeypot is a decoy system. It attracts attackers to study them. It is used for research.

Sandbox

Sandbox isolates untrusted code. It limits its access to resources. It is used for testing.

Code Signing

Code signing verifies the author of software. It uses digital signatures. It is used for updates.

Supply Chain Security

Supply chain security protects against compromised components. It includes verification and auditing. It is a growing concern.

Software Bill of Materials

Software bill of materials lists components and versions. It is used for vulnerability tracking. It is required by some regulations.

Vulnerability Scanning

Vulnerability scanning finds known issues. It uses databases of CVEs. It is automated.

Penetration Testing

Penetration testing simulates attacks. It is done by ethical hackers. It finds real vulnerabilities.

Bug Bounty

Bug bounty rewards finders of vulnerabilities. It is run by companies. It is a way to crowdsource security.

Responsible Disclosure

Responsible disclosure reports vulnerabilities privately. It gives time to fix before publication. It is an ethical practice.

Security Training

Security training educates developers and users. It is ongoing. It is essential for culture.

Culture

Culture values security in the organization. It is set by leadership. It is hard to change.

Leadership

Leadership supports security initiatives. It allocates resources. It is critical for success.

Metrics

Metrics measure security posture. They include vulnerability counts and response times. They are used for improvement.

Continuous Improvement

Continuous improvement learns from incidents. It updates processes and tools. It is ongoing.

Maturity Models

Maturity models assess security capability. They include levels and practices. They are used for benchmarking.

Frameworks

Frameworks provide structure for security. They include NIST and ISO. They are used for guidance.

Standards

Standards define requirements. They are developed by bodies like IEEE and IETF. They are used for interoperability.

Regulations

Regulations are laws that must be followed. They include GDPR and HIPAA. They are enforced by authorities.

Industry Practices

Industry practices are common approaches. They are shared in communities. They are not always documented.

Lessons Learned

Lessons learned are from past incidents. They are documented and shared. They prevent repeat mistakes.

Future Trends

Future trends include AI and quantum computing. They will change security. They are uncertain.

Artificial Intelligence

Artificial intelligence can detect anomalies. It can also be used by attackers. It is a double-edged sword.

Quantum Computing

Quantum computing can break current encryption. It is still in development. It is a future threat.

Post-Quantum Cryptography

Post-quantum cryptography resists quantum attacks. It is being standardized. It is not yet widely deployed.

Homomorphic Encryption

Homomorphic encryption allows computation on encrypted data. It is very slow. It is a research area.

Zero-Knowledge Proofs

Zero-knowledge proofs prove knowledge without revealing it. They are used for privacy. They are complex.

Blockchain

Blockchain is a distributed ledger. It is used for cryptocurrencies. It has limited use in embedded.

Internet of Things

Internet of things connects devices to the internet. It is a large attack surface. It is a growing market.

Industrial Internet of Things

Industrial internet of things connects industrial equipment. It is used for monitoring and control. It is critical infrastructure.

Cyber-Physical Systems

Cyber-physical systems integrate computation and physical processes. They are used in robotics and automation. They are safety-critical.

Robotics

Robotics uses embedded systems for motion and control. It is a major application. It is complex.

Autonomous Vehicles

Autonomous vehicles use embedded systems for driving. They are safety-critical. They are a major challenge.

Medical Devices

Medical devices use embedded systems for diagnosis and therapy. They are regulated. They are safety-critical.

Aerospace

Aerospace uses embedded systems for flight control. It is safety-critical. It is highly regulated.

Automotive

Automotive uses embedded systems for engine control and infotainment. It is a large market. It is safety-critical.

Consumer Electronics

Consumer electronics use embedded systems for appliances and gadgets. It is a large market. It is cost-sensitive.

Industrial Automation

Industrial automation uses embedded systems for factories. It is a large market. It is reliability-critical.

Smart Home

Smart home uses embedded systems for lighting and security. It is a growing market. It is privacy-sensitive.

Smart City

Smart city uses embedded systems for infrastructure. It is a large project. It is complex.

Agriculture

Agriculture uses embedded systems for monitoring and control. It is a growing market. It is remote.

Energy

Energy uses embedded systems for smart grids and meters. It is a large market. It is critical infrastructure.

Telecommunications

Telecommunications uses embedded systems for networking. It is a large market. It is high-performance.

Networking

Networking uses embedded systems for routers and switches. It is a large market. It is high-performance.

Storage

Storage uses embedded systems for drives and controllers. It is a large market. It is reliability-critical.

Graphics

Graphics uses embedded systems for displays and GPUs. It is a large market. It is high-performance.

Audio

Audio uses embedded systems for codecs and processing. It is a large market. It is real-time.

Video

Video uses embedded systems for codecs and processing. It is a large market. It is high-bandwidth.

Image Processing

Image processing uses embedded systems for cameras and vision. It is a growing market. It is compute-intensive.

Machine Learning

Machine learning uses embedded systems for inference. It is a growing market. It is compute-intensive.

Neural Networks

Neural networks are models for machine learning. They are used for classification and prediction. They are large.

Quantization

Quantization reduces the precision of neural networks. It makes them smaller and faster. It may reduce accuracy.

Pruning

Pruning removes unnecessary neurons from neural networks. It makes them smaller and faster. It may reduce accuracy.

Knowledge Distillation

Knowledge distillation trains a small model from a large one. It makes the small model more accurate. It is a technique.

Edge AI

Edge AI runs machine learning on embedded devices. It is a growing market. It is challenging.

Hardware Accelerators

Hardware accelerators speed up machine learning. They include GPUs and NPUs. They are power-hungry.

Neural Processing Units

Neural processing units are accelerators for neural networks. They are efficient. They are a growing market.

Digital Signal Processors

Digital signal processors are for signal processing. They are efficient. They are a mature market.

Field-Programmable Gate Arrays

Field-programmable gate arrays are reconfigurable hardware. They are flexible. They are expensive.

Application-Specific Integrated Circuits

Application-specific integrated circuits are custom hardware. They are efficient. They are very expensive.

System-on-Chip

System-on-chip integrates many components on one chip. It is common in embedded. It is complex.

Multi-Chip Module

Multi-chip module integrates multiple chips in one package. It is used for high-performance. It is expensive.

Chiplets

Chiplets are small chips that are combined. They are a new approach. They are flexible.

3D Integration

3D integration stacks chips vertically. It is used for high-density. It is challenging.

Through-Silicon Via

Through-silicon via connects chips in 3D integration. It is small and fast. It is challenging to manufacture.

Heterogeneous Integration

Heterogeneous integration combines different technologies. It is used for high-performance. It is complex.

Advanced Packaging

Advanced packaging includes 2.5D and 3D. It is used for high-performance. It is expensive.

Fan-Out Wafer-Level Packaging

Fan-out wafer-level packaging is a type of advanced packaging. It is small and thin. It is used for mobile.

Flip-Chip

Flip-chip connects chips with bumps. It is common. It is reliable.

Wire Bonding

Wire bonding connects chips with wires. It is common. It is cheap.

Ball Grid Array

Ball grid array is a package with balls. It is common. It is reliable.

Quad Flat Package

Quad flat package is a package with leads. It is common. It is cheap.

Small Outline Package

Small outline package is a small package with leads. It is common. It is cheap.

Dual In-Line Package

Dual in-line package is a package with pins. It is common. It is easy to use.

Pin Grid Array

Pin grid array is a package with pins. It is common. It is reliable.

Land Grid Array

Land grid array is a package with lands. It is common. It is reliable.

Chip-Scale Package

Chip-scale package is a small package. It is used for mobile. It is expensive.

Wafer-Level Package

Wafer-level package is a package made at wafer level. It is small and cheap. It is a new technology.

Embedded Die

Embedded die is a chip embedded in a substrate. It is used for high-density. It is complex.

Substrate

Substrate is the base of a package. It is made of organic or ceramic. It is important for performance.

Organic Substrate

Organic substrate is made of plastic. It is common. It is cheap.

Ceramic Substrate

Ceramic substrate is made of ceramic. It is used for high-performance. It is expensive.

Flex Substrate

Flex substrate is made of flexible material. It is used for wearables. It is a new technology.

Rigid-Flex

Rigid-flex combines rigid and flex substrates. It is used for complex shapes. It is expensive.

Printed Circuit Board

Printed circuit board is the board that holds components. It is common. It is cheap.

Multi-Layer Board

Multi-layer board has many layers of traces. It is used for complex designs. It