



Generally speaking, the best choice of reference axes is to make them coincide with the directions in which the components of the mass-centre acceleration are expressed.