

For practical applications  $c_v$  is always greater than  $c_P$