

[Cowl Side R/B Assembly Inner Circuit]



- * 1:12V Battery Type * 2:24V Battery Type * 3:FR FOG Relay(*1) FLSH Relay(*2)
- * 4:RR FOG Relay(*1) FLSH2 Relay(*2) * 5:DEFOG Relay(*1) IG2 Relay(*2)

(Cont'd)




(Cont. Next Page)

[Cowl Side R/B Assembly Inner Circuit]

* 1:12V Battery Type * 2:24V Battery Type * 6:IG1 2 Relay (*1) ACC Relay (*2)

(Cont'd)



(Cont'd) 2 2 10A A/C 2 2 15A RR FOG 2 15A FR FOG 2 2 10A MET 2 2 10A IGN 2 10A INJ 2 2 7.5A ST 2 2 10A H/LP LO RH 1 10A H/LP LO LH 2 10A H/LP HI RH 2 2 2 10A H/LP HI LH <u>_1</u>____2 2 2 7.5A ACC (*1) 2 15A CIG (*1)

(Cont. Next Page)

[Cowl Side R/B Assembly Inner Circuit]

