Comments, Comments

Comments are for you – the programmer and your friends...or anyone else human that might read your code.

```
// this is for single line comments
// it's good to put a description at the
  top and before anything `tricky'
/* this is for multi-line comments
    Like this...
  And this....
```



```
BareMinimum | Arduino 1.0.5
File Edit Sketch Tools Help
 BareMinimum §
// Name of sketch
                                       comments
// Brief Description
// Date:
void setup()
  // put your setup code here, to run once:
void loop()
  // put your main code here, to run repeatedly:
```



Three commands to know...

```
pinMode(pin, INPUT/OUTPUT);
  ex: pinMode(13, OUTPUT);
digitalWrite(pin, HIGH/LOW);
  ex: digitalWrite(13, HIGH);
delay(time_ms);
  \underline{ex}: delay(2500); // delay of 2.5 sec.
          -> commands are CASE-sensitive
```



Programming Concepts: Variables

```
ProtosnapProMiniExample2§
                                                      Variable Scope
// Comments go here
// Written by: Joesephine Jones
// Date: April 12, 2013
int sensorValue;
                                                              Global
int ledPin:
void setup()
                                                       Function-level
  // put your setup code here, to run once:
  int setupVariable; 🖊
void loop()
{
 // put your main code here, to run repeatedly:
  int loopScopeVariable
                                                   3.0 United States License.
```

Programming Concepts: Variable Types

Variable Types:

