Circuit #9: Flex Sensor

Code:

```
#include <Servo.h> //include the servo library
Servo myservo;
int potpin = 0; //sets pin 0 to read the flex sensor
int val;

void setup() {
    Serial.begin(9600);
    myservo.attach(9);
}

void loop() {
    val = analogRead(potpin); //get a reading from the flex
sensor
    Serial.println(val);
    val = map(val, 50, 300, 0, 179);
    myservo.write(val);
    delay(15);
}
```