## **Circuit #10: Soft Potentiometer**

## Code:

```
const int RED_LED_PIN = 9;
const int GREEN_LED_PIN = 10;
const int BLUE_LED_PIN = 11;
void setup() {
//No setup necessary but you still need it
void loop() {
 int sensorValue = analogRead(0);
 int redValue = constrain(map(sensorValue, 0, 512, 255,
0),0,255);
 int greenValue = constrain(map(sensorValue, 0, 512, 0,
255),0,255)-constrain(map(sensorValue, 512, 1023, 0,
255),0,255);
 int blueValue = constrain(map(sensorValue, 512, 1023, 0,
255),0,255);
 analogWrite(RED_LED_PIN, redValue);
 analogWrite(GREEN_LED_PIN, greenValue);
 analogWrite(BLUE_LED_PIN, blueValue);
```