Circuit #13: Relays

Code:

```
int ledPin = 2;

void setup() {
    pinMode(ledPin, OUTPUT);
}

void loop() {
    //set the transistor on
    digitalWrite(ledPin, HIGH);
    // wait for a second
    delay(1000);
    // set the transistor off
    digitalWrite(ledPin, LOW);
    // wait for a second
    delay(1000);
}
```