

The LG 3 Ω Fault Table Explained

Sheet LG_3ohm_faults of Minimum_Fault_Current_Calculation.xlsx

IEEE 13-node feeder, DigSILENT PowerFactory, DG out of service

1. What the table is

Each row is one short-circuit calculation in PowerFactory: a **line-to-ground (LG) fault through a fault resistance of 3 Ω** at one node, on one phase, with the DG disconnected. This is the *weakest* fault of the study, the one that gives the smallest fault current. It is used to check that each recloser's pickup is low enough to see every fault of its zone. The calculation uses the *complete method*, i.e. it starts from the load flow, so the loads keep drawing current during the fault.

2. The columns

Column	Meaning
Faulted node	Node where the fault is applied (DL = the distributed load on line 632–671).
Faulted phase	Phase that is short-circuited to ground. Only the phases that exist at the node appear: 645 and 646 have phases B and C, 684 has A and C, 652 only A, 611 only C.
Rf (ohm)	Fault resistance, 3 Ω for every row.
Current at the fault (A)	Current flowing into the fault itself, i.e. to ground at the faulted node.
Current through R1 (A)	Largest phase current measured at R1 (feeder head) during the fault: fault current <i>plus</i> the load current that R1 still carries.
Current through R2 (A)	Largest phase current measured at R2 (on line 632–671) during the fault.
In R1 zone	“yes” if the fault is in the zone R1 must protect (every node except 634).
In R2 zone	“yes” if the fault is downstream of R2 (671, 692, 675, 680, 684, 652, 611).
Yellow cells	The lowest recloser current of each zone: this is If,min used in the pickup check.

3. How to read the numbers

(a) Why is the R1 current larger than the fault current?

Because R1 carries everything that flows into the feeder: the fault current *and* the load current of the phase. Example, row 680 phase B: the fault draws 701.5 A, but R1 measures 1074.4 A. With phasors: $I_{R1} \approx I_{load,R1} + I_{fault} = 411 \text{ A} \angle -173.5^\circ + 701.5 \text{ A} \angle -176.0^\circ \approx 1112 \text{ A}$ (PowerFactory: 1074 A, a little less because the loads draw less while the voltage sags).

(b) Why does R2 show about 465 A for faults at 645, 646 or DL?

These faults are *upstream* of R2 (between the feeder head and R2). With the DG out, no fault current flows through R2; R2 only carries the load beyond it (about 465–470 A). So the “In R2 zone” column is “no” for them and these rows are not used for R2.

(c) Why are rows 671 and 692 identical?

671 and 692 are joined by a switch of zero length, so electrically they are the same point.

(d) Why is node 634 excluded?

634 is on the 0.48 kV side of transformer XFM-1. A 3 Ω fault there draws only about 91 A at 4.16 kV — about the transformer's own load current. That node is protected by its own fuse on the transformer, not by R1 or R2, so it is not part of either recloser zone for this check.

(e) Why is the lowest value at 680 and not at the farthest node 652?

The farthest node (652) gives the smallest current *at the fault* (617.2 A). But the recloser current also contains

the load current of the faulted phase. Phase B carries the least load, so the LG fault on phase B at 680 gives the smallest current *through the recloser*: 1074.4 A at R1 and 878.5 A at R2.

4. What the table proves

Recloser	If,min (yellow)	Where	Pickup used	Check
R1	1074.4 A	680, phase B	720 A	$720 < 1074$ ✓
R2	878.5 A	680, phase B	600 A (curve start)	$600 < 879$ ✓

Both pickups are below the weakest fault current of their zones, so both reclosers detect every fault they must protect against (without DG).

In one sentence: The table lists the weakest fault (LG through $3\ \Omega$) at every node and phase; for each recloser the smallest current it measures for a fault in its own zone is 1074 A (R1) and 879 A (R2), both above the pickups of 720 A and 600 A, so the pickups are correctly set.

5. Likely questions

Why $3\ \Omega$? It is the fault resistance prescribed by the method for the minimum fault (weakest realistic fault).

Why the largest phase current at the recloser? A phase-overcurrent relay operates on the phase with the largest current; that is the current it compares with its pickup.

What changes with DG? With the DG in service the grid share falls; at 100 % DG the weakest fault drops to 577 A at R1 and 368 A at R2, below the pickups (shown in the DG penetration study).