



Watch the video on how to change oil on a BMW R1200 (similar on a R1150).

Parts needed: Oil filter 4 quarts of engine oil

Example of tools needed on the R1200:

E10 Torx

E8 Torx

13 mm Socket

8 mm Allen Socket

BMW Engine Fill Plug (Supplied with your BMW)

Oil Filter Wrench (Order online: MAXWRENCH)

3/8" Ratchet

1/4" Torque Wrench

3/8" Torque Wrench

570	o lorque II	2011011					
#	Part Number	Description		lb	Qty 🖪	Ea	ıch
01 1	11 42 1 460 845	OIL FILTER		0.71	1	(\$25.50
			Oil filter, K75 - This is a bare oil provided. Go here wrench to remove a filter.	fil ¹ for	ter. N	o crush	rings er
02 (7 11 9 902 292	SCREW PLUG - M16X1	,5	0.04	1		\$6.48





Screw plug (M16X1.5).



03 **07 11 9 963 252**

GASKET RING - A16X20-AL

1

\$1.88

Oil plug seal ring, aluminum, 16 x 20.





04 **11 41 1 341 597** O-RING - 22X2,50

1

\$4.38

•

05 07 11 9 901 988	FILLISTER-HEAD SCREW - M6X25-Z2	0.02	2	NA®
05 07 12 9 906 803	ISA SCREW WITH WASHER - M6X25-U2-8.8	0.02	2	\$5.03





06 **11 11 1 341 276**

VENT PIPE

33.07

\$23

\$23.23







Seal ring A20 x 24 Cu. Replacement recommended after disassembly.

11 11 41 1 460 483	SCREW PLUG	0.09	1	\$13.14
Screw plug.				

•

12	11 41 1 342 500	SUCTION TUBE LUBRICATING OIL	0.15	1	\$37.61





13	11 41 1 342 606	INTAKE MANIFOLD, COOLING	0.11	1	\$36.27
•					
					_
14	11 44 1 342 571	COMPRESSION SPRING	0.03	1	\$6.18







15 11 41 1 342 761	THERMOSTAT - 95CEL	71.61	1	\$72.30
•				
16 11 44 1 341 041	BASE	0.02	1	\$5.79
•				
17 17 22 1 342 487	O-RING - 19X4		1	\$5.91
0	O			