Shake and play template

1. Print at actual size and check the template measures 80 mm.
2. Cut out a template. All four on the sheet are the same.
3. Draw around it on thick cardboard and cut it out to make your wearable board.





Cut round the black line