


MINI TILLER - FWMT 210P ENGINE PARTS CATALOGUE




Honour Your Trust

01. HEAD SUBASSEMBLY, CYLINDER / SPARK PLUG (E04)




REF. No.	PART CODE	DESCRIPTION	QTY.
E01-1	G1214E0101000	HEAD SUBASSEMBLY, CYLINDER	1
E01-2	G910110060010	BOLT, CYLINDER HEAD	4
E01-3	G1567E0101000	PLUG, SPARK	1
E01-4	G1230E0102000	GASKET, CYLINDER HEAD	1
E01-5	G905110014000	PIN	2
E01-6	G900306113010	STUD	1
E01-7	G910308034010	STUD	2
E01-8	G900106014010	BOLT	4
E01-9	G1241E0101010	COVER SUBASSEMBLY, CYLINDER HEAD	1
E01-10	G1204E0102000	GASKET, CYLINDER HEAD COVER	1
E01-11	G1703E0103000	TUBE, BREATHER	1

02. CRANKCASE GEAR ASSEMBLY, GOVERNOR (E17)




REF. No.	PART CODE	DESCRIPTION	QTY.
E17-1	G1131E0101000	CRANKCASE SUBASSEMBLY.	1
E17-2	G1536E0101000	SENSOR, ENGINE OIL	1
E17-3	G1660E0101000	GEAR ASSY, GOVERNOR	1
E17-4	G900106014010	BOLT	2
E17-5	G9052E0101000	PIN	1
E17-6	G9041E0102000	WASHER	1
E17-7	G1607E0101000	ARM, GOVERNOR	1
E17-8	G910110015010	BOLT, DRAIN PLUG	2
E17-9	G9041E0101000	WASHER	2
E17-10	G9065E0101000	SEAL, OIL	1
E17-11	G905462056000	BEARING	1

03. CRANKCASE COVER ASSEMBLY (E01)




REF. No.	PART CODE	DESCRIPTION	QTY.
E01-1	T1141E1201000	COVER, CRANKCASE	1
E01-2	T905462056002	BEARING	1
E01-3	G9065E0101000	SEAL, OIL	1
E01-4	G1101E0103000	GASKET, CRANKCASE	1
E01-5	G905108012000	PIN	2
E01-6	G1503E0101110	PLUG SUBASSEMBLY, ENGINE OIL	1
E01-7	G1501E0101110	DIPSTICK SUBASSEMBLY, OIL	1
E01-8	G900108032010	BOLT	6

04. CRANKSHAFT CONNECTING ROD (E03)




REF. No.	PART CODE	DESCRIPTION	QTY.
E03-1	G1330E01270FM	CRANKSHAFT ASSY.	1

05. OIL RING SET / CRANKSHAFT ASSEMBLY (E03)




REF. No.	PART CODE	DESCRIPTION	QTY
E03-1	G1313E0101000	CLIP, PISTON PIN	2
E03-2	T1311E1202000	PISTON	1
E03-3	G1312E0101000	PIN, PISTON	1
E03-4	G1301E0101000	ROD, CONNECTING	1
E03-5	G1320E0101000	RING, THE FIRST	1

06. TRAIN VALVE / CAMSHAFT SUBASSEMBLY (E05)




REF. No.	PART CODE	DESCRIPTION	QTY.
E05-1	T1420E1202000	CAMSHAFT ASSY.	1
E05-2	G1220E1203000	VALVE, EXHAUST	1
E05-3	G1211E1201000	GUIDE, SEAL	1
E05-4	G1213E0101000	SPRING, VALVE	2
E05-5	G1212E1201000	SEAT, Intake VALVE SPRING	2
E05-6	G1212E0101000	Seat, Exhaust Valve Spring	4
E05-7	G1481E0101000	TAPPET, VALVE	2
E05-8	G1470E0101000	LIFTER, VALVE	2
E05-9	G1409E0101000	PLATE SUBASSEMBLY, LIFTER STOPPER	1
E05-10	G910106021010	BOLT, VALVE ADJUSTING	2
E05-11	G1431E0101000	ROCKER, VALVE	2
E05-12	G1410E0101040	NUT , VALVE ADJUSTING	2
E05-13	G1411E0101000	NUT, VALVE LOCK	2

07. RECOIL STARTER (E08)




REF. No.	PART CODE	DESCRIPTION	QTY.
E08-1	T2810E1206G41	STARTER ASSY, RECOIL	1
E08-2	G900106010010	BOLT	9
E08-3	G1930E1201010	SHROUD, CYLINDER BODY	1
E08-4	G1526E0101000	PROTECTOR, OIL	1
E08-5	G900106020010	BOLT	1
E08-6	G1934E0102010	SHIELD, LOWER	1
E08-7	W4405T0002000	SWITCH SUBASSEMBLY, STOP ENGINE	1
E08-8	W4503T0001000	CLIP	1

08. CARBURETOR ASSEMBLY (E11)




REF. No.	PART CODE	DESCRIPTION	QTY.
E11-1	G1610E1208000	CARBURETOR ASSY.	1
E11-2	G1701E0102000	GASKET, AIR CLEANER	1
E11-3	G1601E0101000	GASKET, CARBURETOR	1
E11-4	G1603E0101000	PLATE, CARBURETOR INSULATOR	1
E11-5	G1702E0101000	GASKET, INLET	1

09. AIR FILTER (F02)




REF. No.	PART CODE	DESCRIPTION	QTY
E04-1	G1710E0108000	CLEANER, AIR	1
E04-2	G900406000011	NUT	2

10. MUFFLER ASSEMBLY (F04)




REF. No.	PART CODE	DESCRIPTION	QTY.
F04-1	T1810E1202000	MUFFLER ASSY	1
F04-2	G1801E0101000	GASKET, EXHAUST OUTLET	1
F04-3	G900508000010	NUT	2

11. FUEL TANK ASSEMBLY (F01)




REF. No.	PART CODE	DESCRIPTION	QTY.
F01-1	T1679E1203H20	TANK, FUEL	1
F01-2	T1685E1201000	FUEL TANK CAP	1
F01-3	G1696E0101000	STRAINER , FUEL	1
F01-4	G900106028010	BOLT	1
F01-5	G1693E0101000	OUTLET SUBASSEMBLY, FUEL TANK OIL	1
F01-6	G9068E0103000	TUBE, FUEL	1
F01-7	G9067E0101010	CLAMP	2
F01-8	G900406000011	NUT	2

12. FLYWHEEL / IMPELLER / STARTER PULLEY / IGNITION COIL (E15)



REF. No.	PART CODE	DESCRIPTION	QTY.
E15-1	G910214000010	NUT, FLYWHEEL	1
E15-2	T2802E1201000	PULLEY, STARTER	1
E15-3	G1935E1201000	IMPELLER	1
E15-4	G1351E1202000	FLYWHEEL SUBASSEMBLY	1
E15-5	G1506E1201000	COIL, IGNITION	1
E15-6	G900106025010	BOLT	2

13. THROTTLE CONTROL ASSEMBLY (E13)



REF. No.	PART CODE	DESCRIPTION	QTY
E13-1	G1668E0105010	CONTROL ASSY, THROTTLE	1
E13-2	G1606E0108000	SPRING, GOVERNOR	1
E13-3	G1605E0102010	ROD, GOVERNEOR	1
E13-4	G1604E0102000	SPRING, THROTTLE VALVE RETURNING	1
E13-5	G1608E0101010	SUPPORT SUBASSEMBLY, GOVERNOR	1
E13-6	G900106010010	BOLT	2
E13-7	G910106021010	BOLT, GOVERNOR SUPPORT	1
E13-8	G900406000011	NUT	1



Honour Your Trust

FARMWORLD AGROTECH PRIVATE LIMITED

Office Address:- Plot No. 373, Road-U, Khirasara Industrial Estate, Khirsara,

Taluka – Lodhika, District – Rajkot, 360021 (Gujarat) India.

Email: customercare@farmworld.in | Website: www.farmworld.in