LUMEN 3-shelf bookcase

Introduction and safety

Assembly instructions



Read all instructions before you begin. Keep this leaflet for future use.

Assembly time: about 45 minutes

People needed: 2

Safety

WARNING: Two adults are needed to stand the bookcase upright.

WARNING: Attach the wall strap. An unsecured bookcase can tip over and cause serious injury.

CAUTION: Work on the carton or a soft cloth to protect the panels.

CAUTION: Do not climb on or hang from the bookcase.

Tools

Tools needed (not included): Phillips screwdriver, hammer.

Included in the carton: hex key.



Pictogram: tipping hazard

(no text printed with this symbol)

Contents: 1 Parts 2 Assembly steps 1-10 3 Wall fixing and use

LUMEN 3-shelf bookcase

Parts

Parts list

Check that all parts are present before you begin.

Parts are not shown to scale. Quantities are shown after the letter name.

A Side panel



x2

B Top panel



x1

C Shelf



x2

D Back panel



x1

E Cam bolt

x8

F Cam lock



x8

G Wooden dowel

x8

H Nail

x16

I Wall strap kit

x1

LUMEN 3-shelf bookcase

Assembly: steps 1 and 2

1 **Press 4 dowels G into the top edge of each side panel A.**

Dowels should be firm and straight.



2 **Screw 4 cam bolts E into the inner face of each side panel A.**



LUMEN 3-shelf bookcase

Assembly: steps 3 and 4

3 **Press a cam lock F into each round hole on the shelf ends.**

CAUTION: Work on the carton or a soft cloth to protect the panels.



4 **Slot the shelves onto the cam bolts and turn each cam lock clockwise until it stops.**



LUMEN 3-shelf bookcase

Assembly: steps 5 and 6

5 **Fit the second side panel, then lower the top panel B onto the dowels.**



6 **Nail the back panel on using 16 nails H spaced evenly along every edge.**



H 16 nails in total

WARNING: Once nailed, the back panel cannot be removed without damage.

LUMEN 3-shelf bookcase

Assembly: steps 7 and 8, wall fixing and use

7 **Tip the bookcase upright together and slide it into place.**



WARNING: Two adults are needed to stand the bookcase upright.

8 **Fix the strap to the back of the top panel and to a wall stud or wall anchor.**



WARNING: Attach the wall strap. An unsecured bookcase can tip over and cause serious injury.

Maximum load per shelf: 15 kg.

CAUTION: Do not climb on or hang from the bookcase.