

SECTION 2: FEEDWATER SYSTEM SOP

Purpose: Ensure a consistent and treated water supply to the boiler at the correct pressure and flow rate.

Procedures:

Verify that feed pumps are in operation or set to automatic.

Test check valves and actuator responsiveness.

Confirm softener system functionality and bypass status.

Record flow rate from rotameter or digital sensor.

Check that isolation valves are properly labeled.

Listen for water hammer—may indicate air entrapment.

Inspect for external leaks.

Document make-up water flow, inlet pressure, and pump cycles.

Notes:

Clean suction strainers weekly.

Electrical components should be secured, dry, and inspected regularly.