

SOP #13 – Troubleshooting Techniques for Sump Pump Systems

Applies to: Commercial/industrial basement and pit-mounted sump systems, lift stations, and stormwater pits

1. Common Issues & Diagnostics

Symptom	Likely Cause	Recommended Action
Pump won't turn on	Tripped breaker, float switch failure	Reset breaker, test float/sensor
Continuous cycling	Incorrect float switch setting	Adjust float height, check for debris
No water movement	Airlock or impeller jam	Bleed airlock, inspect/clean impeller
Overheating	Prolonged dry run, blocked intake	Check water level, clear obstructions
Alarm triggered	High water, float/sensor failure	Test alarm float, inspect control panel