

SECTION 8: CONDENSATE RETURN SYSTEM SOP

Purpose: Ensure the efficient and safe return of condensate from heating systems to the boiler for reuse, minimizing water and energy waste.

Procedures:

Check all return lines for leaks, blockages, and thermal insulation.
Confirm condensate receiver tank levels are within operational range.

Monitor pump start/stop cycles and verify no short cycling.

Test pump floats or sensors for proper actuation.

Inspect steam traps for proper drainage and operation.

Listen for water hammer indicating improper trap or air pockets.

Ensure chemical feed systems are calibrated and functional.

Notes:

Return systems should operate under slight positive pressure.

Clean receiver tank strainers and flush lines monthly.