

2. Test Points & Reference Ranges

Test Point	Method	Ideal Value or Range
Return Air Temp	Digital thermostat	72–78°F
Supply Air Temp	Thermometer or sensor	55–65°F
Filter Pressure Drop	Magnehelic gauge	< 0.5 in. wc (change if >1.0)
Fan Motor Amps	Clamp meter	Within 90% of FLA
Outside Air Temp (OAT)	Weather or integrated sensor	Used for economizer logic

3. Emergency Conditions

Event	Response Needed
No Airflow / Fan Tripped	Lockout unit, reset motor or starter
High Vibration	Inspect fan wheel balance, belt tension
Freeze Alarm	Disable economizer, raise mixed air temp
Smoke Detector Shutdown	Confirm no fire, reset unit & detectors