
When the steady-state error response does not require integral control, a PD controller may be used justead.




For the transfer function G(s) = ms2+65

$$\Rightarrow \frac{Y(s)}{R(s)} = \frac{K_p + K_p S}{m s^2 + (b + K_p) S + K_p}$$


The denominator looks like a familiar form (now the system is second order since there is no vitegral control) but the system has a zero.

What happens if we put the controller in the feedback loop instead of the forward path?



Y(5) =

To deal with the steady-state error, we can scale the reference. This has no effect on the stability of the control system since it occurs outside the feed back loop




If we equate the terms to those in the standard form?

 $\frac{Kp}{MS^2+(b+K_0)S+Kp} = \frac{Kplm}{S^2+(b+K_0)lmS+Kplm} = \frac{\omega n^2}{S^2+Z9\omega nS+\omega n^2}$

Kp can be used to set the natural frequency Ko can be used to set the damping ratio

The behavior of the closed-loop poles as we change gains came be viewed graphically:




We can use these gains to achieve specifications is the risk time and peak overshoot simultaneously.

Derivative control can be a powerful tool in achieving the desired performance of a system. However, there is a challenge that pure derivative control is not realizable.

D(s) = Kp+ KpS => numerator has higher order than
the denominator.


Systems with a higher numerator order than denominator cannot be built with passive elements like resistors, capacitors and inductors. They also have issues with causality and power. Consider a comple of example in puts.



fixite input goves on

output changes before the shout does.

In digital systems, we might think of approximating a derivative with a difference.



g(k) 2 y(k) - y(k-1)

This is inherently looking backwards and not the true derivative.

(3)

This approach often results in a very noisy signal since the differencing process amplifies noise.

Suppose y(k) = y(k) + n(k)Then y(k) = y(k) - y(k-1) ΔT


ym-measured output y-actual output n-noise


+ n(k)-n(k-1) Amplify noise difference
by DT

AS DT = 0, the approximation of the derivative gets better but the noise amplification gets worse!

With very clear signals (like a high resolution optical encoder) this may work to approximate the derivative. In other cases, it can result in big problems.

The challenge of physically implementing a derivative also is a deciding factor in considering whether to put the controlled in the feed back or the forward path:





If the reference signal is noisy, it may be preferable to have the controller in the feedback path to avoid differentiating it. The feedback path is also better if the reference input makes step changes (what will the input try to do in such cases?).

The issues with iniplementing pune derivative control can be resolved by using a lead compensator. This is a circuit that can be built (remember the first homework assignment) and filters out the light frequency noise (that will be clear in a comple of weelos).

The lead compansator is just the PD controller with a fast pole:

D(s) = Kp+Kos pole at s=-a

As the value of a increases, the lead compensator resembles the PD controller more closely.

Another difference between choosing to put the PD controller in the feedback path or the forward path is the zero.

 $\frac{Y(s)}{R(s)} = \frac{K\rho + Kos}{ms^2 + (b+Ko)s + K\rho} \qquad \frac{Y(s)}{R(s)} = \frac{K\rho}{ms^2 + (b+Ko)s + K\rho}$

forward path

feedback poth

What is the effect of this zero? There are several ways to look at zeros and this will be the focus of the next lecture. For now, consider breaking up the two parts of the numerator

T(S) = Kp

R(S) = MS²+(b+Kp)S+Kp + S KD

Our Standard 2nd the derivative of the order system form Standard 2nd order form

If Ko << Kp, the system response bols a lot like the standard second order system. In this case, the zero location is far from the imaginary axis since Z = - Kp/Kp is the zero location.

Therefore zeros that are far from the imaginary axis have little impact on the system behadion when they are in the left half plane.

As Ko becomes larger, however, the system response includes more of this derivative term. This can lead to, for instance, greater overshoot to a step response,