

Temporary Traffic Control Basics Refresher

Work Zone Layout

- Taper length and buffer spaces
- Understanding MUTCD expectations
- Common lane closure patterns

Devices

- Cone and drum spacing
- Arrow board modes
- Message sign best practices

Work Zone Setup

- Pre-job steps
- Order of device placement
- Proper photo documentation