
## MAE 6258 Schur\_HW6

```
%Randy Schur
%Adapted from HW5 solutions.
clear
close all
n modes = 6; % number of modes to use in expansion
DVA_mode = 2; % mode to tune DVA to beam properties
L = 1; % length (m)
rhoA = 1; % mass/length (kg/m)
EI = 1; % bending stiffness (N-m^2)
% dimensionless frequencies (pinned-pinned):
lamda = pi*(1:n_modes)';
w_n = lamda.^2*sqrt(EI/(rhoA*L^4));% natural frequencies
w a = w n(2);
% modal damping
zeta = 0.00*ones(size(w_n));
% plot mode shapes
mode_fn = 'ms_pinned_pinned';
% force influence
x f = L/10; % force location
phi_x_f = feval(mode_fn,x_f,1:n_modes,rhoA,L); % mode shapes evaluated at x_f
% constant DVA parameters
x_a = L/4;
p = 1;
phi_x_a = feval(mode_fn,x_a,1:n_modes,rhoA,L); % mode shapes evaluated at x_a
zeta_a = 0.05;
w_a = p*w_n(DVA_mode);
% frequency response at x for system without DVA
wmin = 0.1*w n(1);
wmax = 10*w_n(end);
w = logspace(log10(wmin), log10(wmax), 10001);
G = zeros(1,length(w));
% G(iw) = W(x,iw)/F(iw)
x = L/4;
phi_x = feval(mode_fn,x,1:n_modes,rhoA,L);
% mode shapes evaluated at x
for k = 1:n modes
    Gtilde = 1./(w_n(k)^2-w^2+(1i^2*zeta(k)*w_n(k))*w);
    G = G + (phi_x_f(k)*phi_x(k))*Gtilde;
end
    str = {'Without DVA'};
ampl = 10^{(25/20)};
r1 = 35/w_a;
r2 = 45/w a;
fn1 = @(mu1) r1 - (p^2 - r1^2)/abs((1-r1^2)*(p^2-r1^2) -mu1*p^2*r1^2);
mu = [.004 .0065]; %
G_DVA = zeros(length(mu),length(w));
```


```
G(iw) = W(x, iw)/F(iw) w/ DVA
for i = 1:length(mu)
    % varying DVA parameters
    m_a = mu(i)/phi_x_a(DVA_mode)^2
    % DVA mass (kg)
    k = m a*w a^2
                        % DVA stiffness (N/m)
    c_a = 2*zeta_a*m_a*w_a % DVA damping (N/(m/s))
    % frequency response at x for system with DVA
    H = (m_a*(c_a*w.^3+k_a*w.^2))./(-m_a*w.^2+1i*c_a*w+k_a); % H(iw) (DVA TF)
    num = zeros(1, length(w)); % sum in numerator of <math>W(x_a, s)/F(s)
    den = zeros(1, length(w)); % sum in denomenator of <math>W(x_a, s)/F(s)
    for k = 1:n_modes
        Gtilde = 1./(w n(k)^2 - w.^2 + (1i*2*zeta(k)*w n(k))*w);
        num = num + phi_x_f(k)*phi_x_a(k)*Gtilde;
        den = den + phi \times a(k)^2*Gtilde;
    end
Wxa_F = num./(1-H.*den);
    for k = 1:n_modes
        Gtilde = 1./(w n(k)^2-w.^2+(1i*2*zeta(k)*w n(k))*w);
        G_DVA(i,:) = G_DVA(i,:) + H.*Wxa_F.*(phi_x_a(k)*phi_x(k)*Gtilde)+(phi_x_f(k)*gtilde)
    end
    str{i+1} = sprintf('\mu = %g', mu(i));
end
% convert to dimensionless
d_st = phi_x_a(DVA_mode)*phi_x(DVA_mode)/w_n(DVA_mode)^2;
G = G/d st;
G_DVA = G_DVA/d_st;
% plot frequency response
figure;
semilogx(w, 20*log10(abs(G)), w, 20*log10(abs(G DVA)));
legend(str{:});
set(gca,'XLim',[1e0 1e3]);
hold on
x = linspace(-120, 40, 100);
y1 = repmat(35, size(x));
y2 = repmat(45, size(x));
semilogx(y1, x, 'k:', y2, x, 'k:')
y3 = repmat(25, size(w));
semilogx(w, y3, 'k:')
        m_a =
            0.0020
        k_a =
            3.1171
        c_a =
            0.0079
```




## **Problem 2**

```
clear
close all
alpha = 0.004;
T=10;
m1 = 1;
m2 = .1;
```

```
c=.004;
k=1;
w2 = sqrt(k/m2);
zeta = c/(2*m2*w2);
mu = m2/m1;
s = tf('s');
G1 = 1/m2*(s^2+2*zeta*w2*s+w2^2)/((mu*s^2+2*zeta*w2*s+w2^2)*(s^2+2*zeta*w2*s+w2^2)
K = tf([T 1], [T*alpha 1]);
G2 = (1/m2)/((mu*s^2+2*zeta*w2*s+w2^2)*(s^2+2*zeta*w2*s+w2^2)-(2*zeta*w2*s+w2^2)^2
% G3 = (m2*s^2+c*s+k)/((m1*s^2+c*s+k)*(m2*s^2+c*s+k)-(c*s+k)^2);
% G4 = 1/((m1*s^2+c*s+k)*(m2*s^2+c*s+k)-(c*s+k)^2);
margin(G1*K)
figure
margin(G2*K)
```





Published with MATLAB® 7.13