

Bespiel



Test Druckverlust

Druckverlustberechnung - Teilstrecken

-	A	8-7	. e	D.		F	G	5 U		J	
		Line.			Laires	Coachwin-	Drucke	i i inve	Elneal	Wilderstand	
			100/00		m	distret	Mediust	wider.	wider-	Tellstrecke	
						, m/s	Pa (Rohr)		gianda	Pa	
					aged artists			300	Pa		
ŕ	ZU	1	90,00	125COMPD	3,00	2,04	2,43	0,50	1,25	3,68	
2	ZU	2	30,00	100COMPD	2,00	1,06	0,63	2,00	1,35	1,98	
	ZU	3	60,00	125COMPD	3,00	1,36	1,12	0,80	0,89	2,01	
1	ZU	4	30,00	100COMPD	2,00	1,06	0,63	2,00	1,35	1,98	
5	zu	5	30,00	100COMPD	10,00	1,06	3,16	3,30	2,22	5,38	



Test Druckverlust

Druckverlustberechnung - Ventileinstellungen

A	В	. C	D		19. 15 6.4	G	H	
Liment	Raum		(Conditions	dP.	General	Differenz	Abgleich	Eln-
		streake	80/34			Follow, TS		stellung
				272	Pa		Par	
				(crifen)				
ZU	Wohnzimmer	1; 2;	100ULC	4,30	9,96	5,41	9,71	X
ZU	Esszimmer	1; 3; 4;	100ULC	4,30	11,97	3,40	7,70	A
ZU	Schlafzimmer	1; 3; 5;	100ULC	4,30	15,37	0,00	4,30	12