



CURIO 飛控板接腳定義 (Top)



火箭鳥
創客倉庫

RB — Makers' Depot


CURIO 飛控板接腳定義 (Bottom)



火箭鳥
創客倉庫

RB — Makers' Depot

CURIO 電池配接方式




火箭鳥
創客倉庫

RB — Makers' Depot

CURIO 連接器及轉接方式

Coreless Motor



XDWF-0125WT-02P


SMD, P=1.25mm, Surface Mount

100V 1x2P 2A

SH1.0 ↔ DP 2.54



ESC & UART



JST BM02B-SRSS-TBT(LF)(SN)


JST BM04B-SRSS-TBT(LF)(SN)

SMD, 2P/4P, 1mm



火箭鳥
創客倉庫

RB — Makers' Depot



https://github.com/earlephilhower/arduino-pico/releases/download/global/package_rp2040_index.json

File Edit Sketch Tools Help

Raspberry Pi Pico 2W

sketch_jun17a.ino

```
1 void setup() {
2   // put your setup code here, to run once:
3 }
4
5
6 void loop() {
7   // put your main code here, to run repeatedly:
8 }
9
10
```

Select Other Board and Port

Select both a Board and a Port if you want to upload a sketch.
If you only select a Board you will be able to compile, but not to upload your sketch.

BOARDS

Raspberry Pi Pico - Raspberry Pi Pico/RP2...

Raspberry Pi Pico 2

Raspberry Pi Pico 2W ✓

Raspberry Pi Pico W

Renesas RA8D1 EK

Seeed INDICATOR RP2040


PORTS

/dev/ttyS0 Serial Port

☐ Show all ports

CANCEL

OK



Boot 按鍵使用時機：
燒錄新程式

- 1) 尚未插入 USB
按壓 Boot 鍵後插入 USB
插入 USB 後放開 Boot 鍵
- 2) 已插入 USB
按壓 Boot 鍵後按壓 Reset 鍵
放開 Reset 鍵後放開 Boot 鍵



Reset 按鍵使用時機：

- 1) 燒錄新程式 (如上述)
- 2) 重新執行現有程式
按壓 Reset 鍵後放開