



TECHNICAL MAINTENANCE MANUAL

General Safety Maintenance Manual - UH-SAFE-800

Document ID	MAN-047
Version	v1.0.0
Client	UrbanHive Facility Technologies Pvt. Ltd.
Site	GreenPark Meridian Residency, Whitefield, Bengaluru
Effective date	2024-07-01
Review cycle	Annual or after any major incident

This document is issued under the UrbanHive AMIS asset registry programme. Unauthorized reproduction or distribution outside GreenPark Meridian maintenance contractors is prohibited.

1. Equipment Overview and Technical Specifications

UrbanHive corporate safety and statutory compliance manual for maintenance contractors at GreenPark Meridian Residency - electrical safety, work-at-height, hot work, and incident reporting.

Model code: UH-SAFE-800

Asset registry: Record serial number and installation tower in AMIS before first energization.

Electrical supply: Applicable to all trades: LOTO, permit-to-work, arc-flash PPE Category 2 minimum on LV panels

Environmental limits: Ambient 0-45°C operational; store spare parts below 35°C and 60% RH.

Standards: UrbanHive engineering bulletin UH-ENG-AMIS-2024; applicable Indian Standards as cited per asset class.

Documentation package: This manual, wiring diagram sheet WD-UH-SAFE-800, commissioning checklist CC-047, and spare parts catalogue SP-UH-SAFE-800.

Technicians must verify nameplate data matches AMIS asset record UH-SAFE-800 before applying procedures in this document. Discrepancies must be logged as a data quality ticket to UrbanHive Data Engineering within one business day.

2. Installation Guidelines

All contractors register with UrbanHive vendor portal before site access. Tool inspection tags current. Induction video UH-SAFE-IND-2026 completed by each technician.

Pre-commissioning checks:

- Verify incoming power quality: voltage balance within 2%, THD < 5% on dedicated feeder.
- Confirm earthing resistance ≤ 1 ohm at equipment location; bond to society main earth bar.
- Inspect shipping damage; photograph defects for vendor warranty within 48 hours.
- Complete mechanical alignment, torque logs, and insulation resistance tests per UrbanHive QC form UH-QC-INST-02.

Post-installation: Upload signed commissioning certificate, as-built photos, and warranty start date to AMIS. Tag physical asset with QR code linking to this manual revision v1.0.0.

3. Preventive Maintenance Schedule

UrbanHive mandates the following intervals for GreenPark Meridian. Adjust only with written approval from Head of Maintenance.

- Daily: toolbox talk sign-off; PPE inspection.
- Weekly: first-aid kit check; fire extinguisher pressure gauge.
- Monthly: safety committee walk with RWA representative.
- Quarterly: mock drill - fire / lift entrapment / water ingress.
- Annual: contractor safety audit score must exceed 85% for contract renewal.

Documentation: Each PM visit must generate a service log in AMIS with parts consumed, meter readings, and pass/fail checklist. Missed PM windows trigger automatic escalation to Facility Manager after 72 hours.

4. Troubleshooting Guide

Use isolation procedure: observe symptom ? confirm with meter/test ? apply remediation ? functional test ? document in AMIS.

If fault persists after two visits, escalate to UrbanHive vendor support with fault code and photos.

Fault 01 - Code S101

Symptom: LOTO violation observed on DB

Remediation: Stop work immediately; retrain team; disciplinary per vendor contract.

Fault 02 - Code S205

Symptom: Hot work without fire watch

Remediation: Revoke permit; deploy fire extinguisher and watcher before restart.

Fault 03 - Code S310

Symptom: Harness not anchored above D-ring

Remediation: Correct anchor point; supervisor sign-off before height work resumes.

Fault 04 - Code S402

Symptom: Near-miss: falling object from tower scaffold

Remediation: Install toe boards; barricade zone; incident report within 2h.

Fault 05 - Code S508

Symptom: Chemical SDS not available on site

Remediation: Upload SDS to AMIS; print copy at chemical storage.

Fault 06 - Code S601

Symptom: Electrical panel left open unattended

Remediation: Close and lock panel; verify IP2X finger protection intact.

Fault 07 - Code S702

Symptom: Contractor exceeded authorized work hours

Remediation: Security escort out; update work permit window.

Fault 08 - Code S803

Symptom: Inadequate lighting in pump room

Remediation: Install temporary LED work lights min 200 lux.

Fault 09 - Code S901

Symptom: First aid kit expired items

Remediation: Replace burn gel and gloves; log restock in AMIS.

Fault 10 - Code S1002

Symptom: Emergency assembly point blocked

Remediation: Clear obstruction; notify facility manager; photo evidence.

Fault 11 - Code S1101

Symptom: Noise work outside permitted hours

Remediation: Stop noisy activity; reschedule 10:00-18:00 weekdays only.

Fault 12 - Code S1203

Symptom: Incident report not filed within SLA

Remediation: Complete UrbanHive IR-01 form; notify VP Operations within 30 min.

5. Spare Parts List

Maintain minimum stock at GreenPark Meridian central store (Basement B1, Room ST-04).

Part No.	Description	Min stock
SP-S01	LOTO padlock kit	20
SP-S02	Safety harness Class A	10
SP-S03	First aid refill pack	5
SP-S04	Fire extinguisher 6kg ABC	8
SP-S05	Safety signage board	15
SP-S06	PPE hi-vis vest	50

Reorder when stock falls below minimum. Use UrbanHive procurement portal PR-UH-OPS for approved vendors only.

6. Safety Warnings and Compliance

Zero tolerance for LOTO and harness violations. UrbanHive may suspend vendor access without notice. All incidents reported via AMIS mobile app. Comply with Karnataka Building and Other Construction Workers Act.

Permit requirements: Hot work, confined space, work-at-height, and electrical isolation require digital permit in AMIS before start.

PPE minimum: Safety shoes IS 15298, helmet IS 2925, eye protection IS 5983, gloves appropriate to task.

Incident reporting: Any injury, near-miss, or property damage - complete IR-01 within 30 minutes; notify security desk ext. 9911.

7. Manufacturer Contact and UrbanHive Support

OEM technical support: +91-80-5555-0047 (08:00-20:00 IST)

Email: support-uh-safe-800@urbanhive-vendor.example.com

UrbanHive Ops escalation: maintenance@urbanhiveops.example.com - Priority 1 response within 4 business hours

AMIS helpdesk: Log ticket category `General Safety` with asset_id from tower registry

Emergency (life safety assets): 24x7 hotline +91-80-5555-0911

Revision history: v1.0.0 - Initial release for GreenPark Meridian AMIS integration and UrbanHive contractor certification programme.

End of document MAN-047