

Transverse Loading


- Shear Flow
- Shear Centers
- □ Fastener Spacing


Shear Centers



Built Up Beams








Weldment

Nails

Fasteners

Different Configurations



Example

A box beam is to be constructed from four boards nailed together as shown. If each nail can support a shear force of 30lb, determine the maximum spacing s of nails at B and C so that the beam will support a vertical force of 80lbs.

