-0.2308

```
>> S=[33.33 -10 -10 0 0 0
-10 33.33 -10 0 0 0
-10 -10 33.33 0 0 0
0 0 0 86.67 0 0
0 0 0 0 86.67 0
0 0 0 0 0 86.67]*1e-9
S =
 1.0e-007 *
  0.3333 -0.1000 -0.1000
                                   0
                                             0
                                                       0
  -0.1000 0.3333
                    -0.1000
                                   0
                                              0
                                                       0
  -0.1000
            -0.1000
                     0.3333
                                    0
                                              0
                                                       0
        0
                 0
                         0
                                0.8667
        0
                 0
                           0
                                    0
                                         0.8667
                 0
                          0
        0
                                   0
                                                   0.8667
                                             0
>> C=inv(S)
C =
 1.0e+007 *
   4.0392 1.7313
                      1.7313
                                   0
                                             0
                                                       0
   1.7313
            4.0392
                      1.7313
                                    0
                                              0
                                                       0
                      4.0392
   1.7313
             1.7313
                                    0
                                1.1538
        0
                 0
                           0
                                              0
                 0
                           0
        0
                                  0
                                         1.1538
                 0
                                   0
        0
                          0
                                             0 1.1538
>> Strain=[5 -3 2 1 3 -2]*1e-4
Strain =
 1.0e-003 *
   0.5000 -0.3000 0.2000 0.1000 0.3000 -0.2000
>> Stress=C*Strain'
Stress =
 1.0e+004 *
   1.8465
   0.0002
   1.1541
   0.1154
   0.3461
```