

PMR El Telsizi Kanal Frekansları

Kanal	Frekans	Kanal	Frekans
1	446.00625	9	446.10625
2	446.01875	10	446.11875
3	446.03125	11	446.13125
4	446.04375	12	446.14375
5	446.05625	13	446.15625
6	446.06875	14	446.16875
7	446.08125	15	446.18125
8	446.09375	16	446.19375

PMR446 CTCSS “Gizlilik” Kodları

Kod	Tone (Hz)	Kod	Tone (Hz)	Kod	Tone (Hz)
0	Off	13	103.5	26	162.2
1	67.0	14	107.2	27	167.9
2	71.9	15	110.9	28	173.8
3	74.4	16	114.8	29	179.9
4	77.0	17	118.8	30	186.2
5	79.7	18	123.0	31	192.8
6	82.5	19	127.3	32	203.5
7	85.4	20	131.8	33	210.7
8	88.5	21	136.5	34	218.1
9	91.5	22	141.3	35	225.7
10	94.8	23	146.2	36	233.6
11	97.4	24	151.4	37	241.8
12	100.0	25	156.7	38	250.3

Yeni model PMR telsizlerde kod 39’dan itibaren 121’e kadar DCS olarak devam eder:

Kod	DCS	Kod	DCS	Kod	DCS	Kod	DCS	Kod	DCS	Kod	DCS	Kod	DCS	Kod	DCS
39	023	50	072	61	152	72	244	83	343	94	432	105	606	116	723
40	025	51	073	62	155	73	245	84	346	95	445	106	612	117	731
41	026	52	074	63	156	74	251	85	351	96	464	107	624	118	732
42	031	53	114	64	162	75	261	86	364	97	465	108	627	119	734
43	032	54	115	65	165	76	263	87	365	98	466	109	631	120	743
44	043	55	116	66	172	77	265	88	371	99	503	110	632	121	754
45	047	56	125	67	174	78	271	89	411	100	506	111	654		
46	051	57	131	68	205	79	306	90	412	101	516	112	662		
47	054	58	132	69	223	80	311	91	413	102	532	113	664		
48	065	59	134	70	226	81	315	92	423	103	546	114	703		
49	071	60	143	71	243	82	331	93	431	104	565	115	712		

Derleyen: Hasan Karaahmet (TA1HYK)