

User's Manual for Pair Software

1. Initial Use

Before initial use, please make sure correct installation of **Pair** software and **USB adaptor driver** software. Firstly, put the enclosed disk of this Meter into the computer's CD-ROM, open "**Driver Installation**" file up, and then installation according to the specified steps(during the installation process , default path is recommended to avoid unnecessary problems) ; open "**Pair**" file up , click "**setup.exe**" twice, and follow the hint to install. When finishing, the software is available for communication with the Meter.

• 2. Software Specification

1. The wireless communication module and the PC machine, open the instrument, set up the instrument for wireless communication state.
2. Select COM terminal communicated with the Meter

Install the driver program, and connect the communication wire with the PC, find out the "Silicon Labs CP210x USB to UART Bridge (short name of mapping COM terminal)" in the list by steps: desktop→ my computer→ right-click menu→ select properties →hardware →device manager →terminals" (as shown in Figure 1). ; namely select this terminal. (as shown in Figure 2).




Figure 1




Figure 2

3. Clicked the button as "Open Com", the button of "Scan" is enable on the "Pair Operator" group, as shown in Figure 3.




Figure 3

4. Clicked the button as "Scan", Scanning process begins, After the scan is

shown in Figure 4.




Figure 4

5. Clicked the button as "Paired", Pairing process begins, The pair is shown in Figure 5.




Figure 5

6. Pairing completed, please close the software, and reinsert the U disk.