

CYPHER CYPHLIB LIBRARY

SUMMARY SHEET

I.A. Cunningham

05-Jun-1987

The following is a summary sheet of routines supported by the CYPHLIB library for C programs on the 68000. More detailed information is available in the source code documentation.

FILES

The library source code is contained in two files.

CYPHLIB.C - C source
CYPHLIBS.S - assembly language source
@CYPHLIB.SUB - command procedure to generate a new version of the library

PROCEDURES SUPPORTED

The following procedures are supported by the library. In the following, x,y refer to float variables of x and y coordinates (scaled units, scaled by the necscale routine), ix,iy refer to integer unscaled coordinates (bottom left is 0,0), im refers to line mode, and it refers to line type.

it - 0 solid line
 1 dashed line
 2 dotted line
 4 rubber band lines (4 solid, 5 dashed, 6 dotted)
im - 0 set pixels
 1 reset pixels
 2 complement pixels

Don't call in CPM-3 version → necini(); - set display size to default 480,240, enter text mode
necrst(ix,iy); - set display size, enter text mode
necout(i); - send character to driver code (via TRAP 15)
necclear(); - clear screen and home cursor
necscale(x,y); - set graphics scales so that (0,0) to (x,y) fills screen
necuorg(ix,iy); - set origin
necsorg(x,y); - set origin
nexexit(); - exit graphics mode
necmove(x,y); - move
necum(ix,iy); - move
necmr(x,y); - move relative
necumr(ix,iy); - move relative
necdaw(x,y,it,im); - draw line
necud(ix,iy,it,im); - draw line
necdr(x,y,it,im); - draw line relative
necudr(ix,iy,it,im); - draw line relative
necbox(x1,y1,x2,y2,it,im); - draw box
necwind(ix,iy); - set position of top left corner of display window
necpage(i); - advance display by i pages (+ or -), enter text mode
necstring(str,izoom,islant,iinv); - write string to screen
neczoom(i); - set display zoom factor
char *cyver(); - return pointer to version string
int bank80(); - return currently set Z80 bank
char *cytime(); - return time string
char *date(); - return date string

abort(i);	- set abort enable flag
setclk(1);	- set 4 Hz interrupt clock counter (long)
long getclk();	- return 4 Hz interrupt clock counter
enclk(i);	- set 4 Hz interrupt enable flag
int getib();	- return EPROM character input redirection byte
int getob();	- return EPROM character output redirection byte
setib(b);	- set EPROM character input redirection byte
setob(b);	- set EPROM character output redirection byte
blink(i);	- set cursor blink enable flag
long bdos(i,11);	- bdos functions
long bios(i,11,12);	- bios direct call functions
cydac1(i);	- output to digital to analog converter 1
cydac2(i);	- output to digital to analog converter 2