



PMP
2.1




irnas

PMP
2.1





CON9

BAT
ENABLE
S1



S2



irnas

PMP
2.1



P13



P14



P15



P16



P17



P18



P19



P20




P21



BAT
ENABLE
S1




S2



Hex key



CON9



CON4



MS1

CON5



MS2



RST
SW1




R37
R36

irnas

PMP
2.1




irnas



U11

U6

P+ P- B-
B+ P- B-



U11

U6

U12

B+ P- B-
P+ P- B-

B+ P- B-
P+ P- B-

U11

U9

P+ P- B+ B-

U11

U9

P+ P- B+ B- GND