

Offcuts go in the **blue bin.**

Every sheet of plasterboard that goes in here is recycled into gypsum instead of being buried. It only works if plasterboard is the only thing in it.



1

Lift the panel

It's hinged at the top and held up by a strut.

2

Slide the board in

Offcuts, part sheets, whole sheets, cornice. Break big sheets to fit more.

3

Screws and timber out

No batts, no foil-backed board, no rubbish. Nothing that isn't plasterboard.

4

Shut it at knock-off

Keeps the rain out. Full? Tell the site manager.