



Online guide

Pawl

0000 195 7200


Bin **T5** | 5 spares per kit | **S2** supervision

HT 135 — rewind starter

Manual-listed pawl: 4116 195 7200. Shown in rewind starter [4182](#) [190](#) [4001](#).

Item 8 | Qty listed: 1

HT 135-Z spare-parts list, 10/28/2024. Drawing p. 5; parts table p. 6.




MS 261 — rewind starter

Manual-listed pawl: 1125 195 7200. Shown in fan housing [1141](#) [080](#) [2104](#).

Item 8 | Qty listed: 2

MS 261 C-M spare-parts list, 10/02/2023. Drawing p. 19; parts table p. 20.



MS 462 — rewind starter

Manual-listed pawl: 1125 195 7200. Shown in fan housing [1142](#) [080](#) [2102](#).

Item 10 | Qty listed: 2

MS 462 C-M Z spare-parts list, 10/29/2024. Drawing p. 21; parts table p. 22.

