



Online guide

Filler cap

0000 350 0533


Bin **T0** | 2 spares per kit | **AS1** supervision

MS 462 — fuel tank

Fuel filler cap; includes seal (item 6). The same part is used on the oil tank.

Item 5 | Qty listed: 1

MS 462 C-M Z spare-parts list, 10/29/2024. Drawing p. 23; parts table p. 24.



MS 462 — oil tank

Oil filler cap used in both MS 462 crankcase configurations; includes seal (item 9).

Item 8 | Qty listed: 1

MS 462 C-M Z spare-parts list, 10/29/2024. Drawing p. 3; parts table p. 4.

