



Online guide

Oil pump


1142 640 3200

Bin **B4** | 1 spare per kit | **S2** supervision

MS 462 — oil pump

Assembly includes items 2–8. Driven by worm 1128 640 7112.

Item 1 | Qty listed: 1



MS 462 C-M Z spare-parts list, 10/29/2024. Drawing p. 13; parts table p. 14.