

Flux Capacitor

DR. E. BROWN ENTERPRISES
24 HR. SCIENTIFIC SERVICES



R18801986

| Single button actions | | |
|------------------------------------------|--------------------------------------------------------------|------------------------------------------|
| 1 Play "key1.mp3" [3001] | 2 Music Player : Previous song [3002] | 3 Play "key3.mp3" [3003] |
| 4 Play "key4.mp3" [3004] | 5 Music Player : Play/Stop [3005] | 6 Play "key6.mp3" [3006] |
| 7 Play "key7.mp3" [3007] | 8 Music Player : Next song [3008] | 9 Play "key9.mp3" [3009] |
| ★ Start command sequence | ○ Time Travel | # Abort command |
| | ↑ Volume + | |
| ← Chase speed - | OK Execute command | → Chase speed + |
| | ↓ Volume - | |

Flux Capacitor

DR. E. BROWN ENTERPRISES
24 HR. SCIENTIFIC SERVICES



R10001986

| | | |
|-----------------------------------------|----------|---------|
| Select chase sequence style | *1x↔ | 301x |
| Disable flux sound | *20↔ | 3020 |
| Enable flux sound | *21↔ | 3021 |
| Enable flux sound (30 seconds) | *22↔ | 3022 |
| Enable flux sound (60 seconds) | *23↔ | 3023 |
| Set relative flux volume level (0 - 3) | *3x↔ | 303x |
| Select volume level (00 - 19) | *3xx↔ | 33xx |
| Enable volume knob | *399↔ | 3399 |
| Set minimum box light level (0 - 4) | *40x↔ | 340x |
| Music Player : Set folder number | *5x↔ | 305x |
| Music Player : Shuffle off | *222↔ | 3222 |
| Music Player : Shuffle on | *555↔ | 3555 |
| Music Player : Go to song 000 | *888↔ | 3888 |
| Music Player : Go to song xxx | *888xxx↔ | 3888xxx |
| Play "keyX.mp3" (X = 1 - 9) | *50x↔ | 350x |
| Toggle positive IR feedback | *62↔ | 3062 |
| Toggle IR command entry feedback | *63↔ | 3063 |
| Toggle IR remote command lock | *70↔ | 3070 |
| Re-activate or connect WiFi | *77↔ | - |
| Reset chase speed | *80↔ | 3080 |
| Toggle usage of Speed knob | *81↔ | 3081 |
| Say current IP address | *90↔ | 3090 |
| Enter TCD remote control mode* | *95↔ | 3095 |
| Quit TCD remote control mode* | - | 3097 |
| Restart the Flux Capacitor** | *64738↔ | 3064738 |
| Delete static IP address** | *123456↔ | 3123456 |
| Forget learned IR rem. control** | *654321↔ | 3654321 |

Control of FC through TCD requires BTTFN connection.

* Remote controlling the TCD keypad requires BTTFN connection.

Keys 0-9 and OK are sent as brief presses; *x sends key x as "held".

quits remote control mode. ** Not through HA/MQTT