

Single button actions		
1 Play "key1.mp3" [3001]	2 Music Player : Previous track [3002]	3 Play "key3.mp3" [3003]
4 Play "key4.mp3" [3004]	5 Music Player : Play/Stop [3005]	6 Play "key6.mp3" [3006]
7 Play "key7.mp3" [3007]	8 Music Player : Next track [3008]	9 Play "key9.mp3" [3009]
★ Start command sequence	0 Time Travel	# Abort command
	↑ Volume +	
← Chase speed -	OK Execute command	→ Chase speed +
	↓ Volume -	

Flux Capacitor

DR. E. BROWN ENTERPRISES
24 HR. SCIENTIFIC SERVICES



Select chase sequence style	*1x	301x
Disable flux sound	*20	3020
Enable flux sound	*21	3021
Enable flux sound (30 seconds)	*22	3022
Enable flux sound (60 seconds)	*23	3023
Set relative flux volume level (0 - 3)	*3x	303x
Select volume level (00 - 20)	*3xx	33xx
Enable volume knob	*399	3399
Set minimum box light level (0 - 4)	*40x	340x
Music Player : Set folder number	*5x	305x
Music Player : Shuffle off	*222	3222
Music Player : Shuffle on	*555	3555
Music Player : Go to track 000	*888	3888
Music Player : Go to track xxx	*888xxx	3888xxx
Play "keyX.mp3" (X = 1 - 9)	*50x	350x
Toggle positive IR feedback	*62	3062
Toggle IR command entry feedback	*63	3063
Toggle IR remote command lock	*70	3070
Re-activate or connect WiFi	*77	-
Reset chase speed	*80	3080
Toggle usage of Speed knob	*81	3081
Say current IP address	*90	3090
Enter TCD remote control mode*	*95	3095
Quit TCD remote control mode*	#	3097
Disable Car Mode**	*990	3990
Enable Car Mode**	*991	3991
Restart the Flux Capacitor**	*64738	3064738
Delete static IP address**	*123456	3123456
Forget learned IR rem. control**	*654321	3654321

* Remote controlling the TCD keypad requires BTTFN connection.

Keys 0-9 and OK are sent as brief presses; *x sends key x as "held".

quits remote control mode.

** Not through HA/MQTT-INJECT