

SID



R10001986

Single button actions		
1 Games: New game	2	3
4	5 Games: Pause	6
7	8	9 Games: Quit
★ Start command sequence	0 Time Travel Siddly: Fall down	# Abort command
	↑ Brightness + Games: Rotate/Up	
← Games: Left	OK Execute command	→ Games: Right
	↓ Brightness - Games: Down	

Command sequences	IR	TCD/HA
Set idle pattern 0	*10	6010
Set idle pattern 1	*11	6011
Set idle pattern 2	*12	6012
Set idle pattern 3	*13	6013
Set idle pattern 4	*14	6014
Switch to idle mode	*20	6020
Start Spectrum Analyzer	*21	6021
Start Siddly game	*22	6022
Start Snake game	*23	6023
Toggle "strictly movie patterns"	*60	6060
Spectrum Analyzer: Toggle peaks	*61	6061
Spectrum Analyzer: Toggle Mirror	*64	6064
Toggle positive IR feedback	*62	6062
Toggle IR command entry feedback	*63	6063
Toggle IR remote command lock	*71	6070
Re-activate or connect WiFi	*77	-
Display current IP address	*90	6090
Enter TCD remote control mode*	*96	6096
Quit TCD remote control mode*	-	6097
Set brightness level (00-15)	*4xx	64xx
Disable Car Mode**	*990	6990
Enable Car Mode**	*991	6991
Restart the SID**	*64738	6064738
Delete static IP address**	*123456	6123456
Forget learned IR rem. control)**	*654321	6654321

* Remote controlling the TCD keypad requires BTTFN connection.

Keys 0-9 and OK are sent as brief presses; *x sends key x as "held".

quits remote control mode.

** Not through HA/MQTT-INJECT