

TIRES

Tire tread	Worn tires can cause slipping and sliding, especially if the road is wet. Tire tread shouldn't be less than 2/32 of an inch.
Tire pressure	Low tire pressure can affect your car handling and speed. The proper inflation pressure for your tires can be found on the Tire and Loading Information label on the driver's side door edge or in your owner's manual.

GLASS SURFACES

- Keep the windshield and windows clean — inside and outside.
- Keep your window washer fluid full.
- Completely clear snow, ice, or frost from all windows before driving.
- Don't hang things from your mirror or clutter your windows with decals or items that block your view.
- Follow your vehicle manufacturer's recommendations for replacing your wipers.