AMZFAST

Quick Start Guide

27" UHD LED Monitor

AMZG27X6U

Scan QR-Code for more instructions.
amzfast.net

1 Warning! Important Safety Instructions

Please read the below warnings carefully before you install and use our product.

⚠ Warning ⚠

RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: DO NOT REMOVE COVER TO REDUCE RISK OF ELECTRIC SHOCK.

There are no user serviceable parts inside. Be sure to have repairs performed by qualified service personnel.

⚠ This symbol means that dangerously high voltage is present inside. Any form of contact with any part inside the product is dangerous.

⚠ This symbol reminds you of the important instructions that come with the operation and maintenance of this product.

* Do not place this machine near or over electric heaters or radiators, or in places exposed to direct sunlight.
* Do not place heat-generating objects (such as candles, ashtrays, incense, flammable gas or explosive substances, etc.) near the product.
* Do not place containers filled with water on this machine as this may result in a fire or electric shock hazard.
* Do not expose the product to oily substances or chemical agents, as this may cause corrosion of the product casing.
* Do not expose this machine to rain or near water(e.g. near a bathtub, sink, kitchen sink, or laundry sink, in a wet basement, or near a swimming pool).
  If the machine gets wet accidentally, please unplug the power cord or power adapter immediately, and then promptly contact an authorized dealer for further assistance. When cleaning the monitor, be sure to use a dry, soft cloth that does not contain volatile substances. Before cleaning, be sure to unplug the power cord or power adapter.

* Do not overload wall outlets, extension cords, or integral convenience receptacles as this may result infire or electric shock.
*The power cord or power adapter should be placed in a location where it will not be stepped on or squeezed by objects above or next to it, and special attention should be paid to the wires at the plug, at the integral convenience receptacles and at the outlet of the machine.
*To better protect this machine in lightning weather or when it is left unattended or unused for a long time, please unplug its power cord or power adapter, and disconnect the cable system.
This prevents damage to the machine during a lightning storm or in the event of a power surge on the power line.
*Before connecting the AC power cord to the power adapter or monitor power interface (subject to the actual product style), please make sure that your local power supply meets the requirements of power adapter or monitor input voltage.
*Be sure not to insert any metal objects into the holes of this machine, otherwise it may cause a danger of electric shock.
*Do not touch the inside of this machine to prevent electric shock. Only qualified technicians are allowed to open the cover of this machine.
*Make sure that the power cord plug or power adapter can be securely inserted into the outlet. When disconnecting the power cord, make sure to firmly grasp the power plug or power adapter and unplug it from the outlet.
*Do not touch the power cord or power adapter with wet hands.
*If the machine does not operate normally, especially if it emits any unusual sound or smell, unplug the power outlet immediately and contact an authorized dealer or service center for further assistance.
*If you plan to leave the monitor unused for an extended period of time, or if you are going to be away from home (especially if there are children, the elderly, or people with disabilities left alone), be sure to unplug the power plug or power adapter from the outlet.
Accumulated dust may cause sparks and heat from the power cord or power adapter or cause the insulation of the power cord or power adapter to deteriorate, resulting in electric shock, leakage or fire.
*After the monitor is moved from a low temperature place to a warm area, it should be placed for a period of time before powering on, so that the condensation inside the monitor can be fully dissipated and dried.
*The power supply voltage will be marked on the back of the monitor.
*If you plan to install this product in dusty, high or low temperature, high humidity, chemical-containing environments and 24-hour use locations (such as airports or train stations, etc.), be sure to contact an authorized service center for further assistance. Otherwise, the monitor may be severely damaged.
*To disconnect the power from the device, the power cord or power adapter plug must be unplugged from the machine, so the power cord or adapter plug should be easily accessible.
*Children are prohibited from climbing on this product.
*Keep the accessory parts out of the reach of children.
*Do not install this product in an unstable location, such as a wobbly shelf, sloping floor, or a location subject to external vibration.
*Do not drop the product or subject it to shock. If the product is damaged, please disconnect the power supply and contact the service center in time for further assistance.

IC Statement:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Technical Specifications:

Operating temperature:-10°C ~ 35°C

FC

Federal Communications Commission Declaration of Conformity

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this devicemust accept any interference received, including interference that may cause undesired operation.

The following local Manufacturer/Importer is responsible for this declaration:


Product:	UHD LED Monitor
Model Number:	AMZG27X6U
SKU Number:	AMZG27X6U
Name of Responsible Party:	Global Q International Ltd.
Address of Responsible Party:	3471 N, Union Drive Olney, IL 62450

a:The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.
This device is not intended to be used on soft support surfaces such as bedding, blankets, etc.
b:The mains plug / adapter is used as the disconnect device, and the disconnect device shall remain readily operable.


HDMI®
HIGH-DEFINITION MULTIMEDIA INTERFACE

2 Installation of the base

Wall-mounted screw:M4*10mm VESA mounting:75*75mm




3 Button Function description and Cable connection



1.Press menu key display OSD and select.
2.Press E key display source(HDMI/DP optional).
3.Press down key cross hair;Press up key brightness.

POWER OFF/ON ---------- ⏻
E-EXIT MENU/SELECT SOURCE ---------- E
UP/BRIGHTNESS ---------- ▲
DOWN/VOLUME ---------- ▼
M-MENU/SELECT ---------- M



Note:
Picture for reference purposes only.