

Dean,
Here are some notes and drawings about the bathroom.

1. The subway tile should be offset as shown in the image, and like in the kitchen. About a two inch offset should be good.
2. The grout we have is from Lowes; it is a "replacement for sanded and unhandeled grout". Buy as much as you need. Use it for all the tile, floor and wall.
3. The floor tile should be oriented as shown, offset by half a tile.
4. The accent tile panels should be centered on the insert.
5. The vanity should be centered on the medicine cabinet.
6. We haven't picked a wall color yet; if we do we will get the color code from home depot or Lowes and get that to you. Otherwise, please go ahead and put primer on the walls and we'll take care of the paint when we get home.
7. Baseboards should be simple 1x4 material, painted white.
8. If you need to open up more of the back wall of the closet to deal with plumbing, go ahead.
9. If you need water for cutting tile, use the spigot at waist height near the bathroom. The others will be in use for a watering system.
10. The easy water cutoff is outside. Water will be on while we're gone.
11. The water heaters will be off at the breaker. Don't groan too much if you open my panel.

