```
smacc::SmaccClientBehavior

+ stateMachine_
+ currentState
+ currentOrthogonal

+ SmaccClientBehavior()
+ ~SmaccClientBehavior()
+ getName()
+ onEntry()
+ onExit()
```

+ postEvent()
+ requiresClient()
+ requiresComponent()

+ postEvent()

- configureEventSourceTypes()



move\_base\_z\_client ::CbNavigateGlobalPosition

+ initialPoint + initialYaw

- moveBaseClient\_

+ CbNavigateGlobalPosition() + CbNavigateGlobalPosition() + onEntry()

+ goToRadialStart() + readStartPoseFromParameter

Server() + onExit()