


TORNADO



TWF-30

TWF-29

شكراً لإختيارك مروحة حائط تورنيدو

ELARABY

موديل
TWF-29
TWF-30

دليل التشغيل
مروحة حائط

How to use remote control TWF-30

- Push button No.1 to operate or stop.
- Push (Hi-Comfort) button No.2 , to change between speeds randomly and automatically and to stop push it again.
- Push button 3 to operate the timer as following:


Pushing Times	No.of Operating hrs
1	1
2	2
3	4
4	8

- Push button 4 to determine the speed level as follow:

Push Times	Speed Level
1	Low
2	Med
3	High

- Push button 5 to operate or stop oscillation motion.

Note: This property will not operate unless the oscillation motion button at the top of motor cover is at position (0).



- Push button 1 to turn on or off.
- If you want to turn on or off, press the button (1) for the first time, then release it. If you want to turn off, press the button (1) for the second time, then release it.
- If you want to change the speed, press the button (2) for the first time, then release it. If you want to change the speed again, press the button (2) for the second time, then release it.
- If you want to set the timer, press the button (3) for the first time, then release it. If you want to set the timer again, press the button (3) for the second time, then release it.
- If you want to set the oscillation, press the button (4) for the first time, then release it. If you want to set the oscillation again, press the button (4) for the second time, then release it.

عدد مرات الضغط	عدد ساعات التشغيل
١	١
٢	٢
٤	٤
٨	٨

- Push button 4 to determine the speed level as follow:

عدد مرات الضغط	مستوى السرعة
١	منخفضة
٢	متوسطة
٣	مرتفعة

- Push button 5 to operate or stop oscillation motion.

Note: This property will not operate unless the oscillation motion button at the top of motor cover is at position (0).

الصيانة الوقائية

- When not in use, unplug from outlet.
- When you take off the guard , be sure that plug is out .
- Wipe the dust on the body or blade with damp cloth .
- When any fault occurs during use, stop to use plug out , and contact your service center.
- Any service operation should be done by an authorized service centre.



Cautions

- Attention is required when a child is near the fan .
- For safety, Fasten The screws and be sure That the front and rear, guards are assembled tightly.
- Do not operate with damaged cord or plug.

تحذيرات

- Keep children away from the fan in case of children's proximity.
- Do not disassemble the fan without following the instructions.
- Do not damage the fan or its parts.
- Do not damage the fan or its parts.
- Do not use the fan with damaged power cord or plug.

قبل تقديم منتجات تورنيدو العربي إلى الأسواق يتم انتاجها وفق معايير محددة للجودة ومراقبة الإنتاج وذلك من أجل إرضاء العملاء والمستهلكين إلى أقصى درجة ممكنة.



How to Install the Fan

- 1- Select the installation position on the wall.
- 2- Fix mounting plate on the wall with 2 screws.
- 3- Set the fan on the mounting plate, and fasten it by fix screw.
- 4- To adjust air flow direction,Push guard to wanted position.

How to use TWF-29

- 1- Insert the plug into electric source .
- 2- Pull the switch string and select the wanted speed.
 - ORANG : Low Speed
 - Green : Med. Speed
 - Blue : High Speed
 - Gray : Off
- 3- If you want to stop the oscillation motor press the osc switch shown in fig. 1.



طريقة إستخدام TWF-29

- 1- وصل التيار الكهربائي للمروحة.
- 2- إسحب الشاداد لأسفل واختر سرعة المروحة التي ترغبها كما يلي :

 - البرتقالي : سرعة منخفضة
 - الأخضر : سرعة متوسطة
 - الأزرق : سرعة مرتفعة
 - الرمادي : ايقاف التشتتيل

- 3- وإذا أردت ايقاف الحركة الترددية اضغط زر الحركة الترددية الموضح بشكل ١.

طريقة إستخدام TWF-30

Usage without remote control

- Push (ON/OFF) key to run the fan starting first speed .
- To choose Medium speed push again, to choose higher speed push again.
- To start or stop oscillation :
 - Manually : press switch (0/1) in the motor cover to be in position (1) (fig. 1).
 - By Remote: press switch (5) in the remote when the position of the switch (0/1) in (0).

طريقة إستخدام TWF-30

- الاستخدام بدون الريموت
 - لتشغيل المروحة اضغط زر (تشغيل/ايقاف) حيث تعمل المروحة على السرعة الأولى.
 - لزيادة السرعة إلى الثانية اضغط مرة أخرى ولزيادة إلى السرعة الثالثة اضغط مرة ثالثة.
 - لايقاف او ايقاف الحركة الترددية :
 - يدوياً : من خلال الضغط على الموجود أعلى غطاء المروحة ليصبح علىوضع (0/1)
 - (انظر الشكل رقم 1).
 - باستخدام الريموت : من خلال الضغط على مفتاح رقم (5) من الريموت مع وضع مفتاح (0/1) على الوضع (0).

All TORNADO El-Araby Products are manufactured under defined quality and production control, in order to provide a maximized satisfaction to our customers.

Technical Specifications

RATED VOLTAGE	Power Consumption	Speed
220V - 50Hz	60 ± 3 WATT	1025 - 1175 RPM

جهد التشغيل	القدرة	السرعة
٢٢٠ فولت	٣٠ وات	١١٧٥ - ١٠٥ نصف دقيقة

How to assemble the Fan

- 1- Unpack the carton and take out the sets.
- 2- Set the rear guard in proper position as shown in Fig(1),fasten it with the face fitting ring, as the rear guard be fit with two plastic pins in the fitting ring, then fasten the fitting ring again (in direction of clockwise).
- 3- Install the blade on to the shaft . check that blade is properly positioned as the shaft pins should be put in correct way in blade cavity, be careful for blade angle, then fasten withSpinner (in direction of counter-clockwise).
- 4- Check the proper assembly of guard ring and front ditch of the guard ring and guard clips in the lowest position and Tornado mark horizontal.
- 5- Do not tighten the guard clips bolt before assembling the front and back guard but make it slightly opened.
- 6- When you press front guard to lock with the back guard press it at nethermost position then at sides then upper position then assure fastening of guard clips bolmaking sure that Tornado mark is Horizontal.
- 7- تركيب الشبكة الأمامية على الشبكة الخلفية ضغطها من الأسفل ثم الجوانب ثم من الأعلى لتغلق جيدا ثم اربط مسمار الكلبس جيدا لإتمام عملية التثبيت أخذنا في الاعتبار أن علامة تورنيدو في وضع أفقي.
- 8- فك الكرتونة وأخرج المكونات الداخلية.
- 9- ركب الشبكة الخلفية في المكان المحدد كما هو بالرسم شكل رقم (1) وثبتها بإستخدام صامولة الوش بحيث تدخل الشبكة الخلفية داخل دليلي البلاستيك ثم قم بربط صامولة الوش مرة أخرى (بدوران الصامولة في اتجاه عقارب الساعة).
- 10- ثبت الريشة على عمود المotor وتأكد بحيث يدخل بنز عمود المotor في التجويف المخصص لها تماماً بالريشة وأحرص على زاوية الريشة جيدا عند التداول ثم اربط بإستخدام صامولة ربط الريشة (اسپنر) وذلك بدوران الصامولة في اتجاه عقارب الساعة.
- 11- تأكد من أن الطوق مثبت في الشبكة الأمامية بحيث يكون سلك الشبكة في المجرى الأمامي في طوق الشبكة ومكان كلبس الطوق في الأسفل وعلامة تورنيدو أفقية.
- 12- لا تحكم إغلاق مسمار كلبس الطوق قبل تركيب الشبكة الأمامية مع الخلية ولكن اجعله مفتوحاً مسافة بسيطة جدا.
- 13- أثناء ضغط الشبكة الأمامية على الشبكة الخلفية ضغطها من الأسفل ثم الجوانب ثم من الأعلى لتغلق جيدا ثم اربط مسمار الكلبس جيدا لإتمام عملية التثبيت أخذنا في الاعتبار أن علامة تورنيدو في وضع أفقي.