



Molex Microfit 3.0 Extractor using Staplers (DIN 24/6)



VIEW IN BROWSER

updated 10. 2. 2023 | published 10. 2. 2023

Summary

A contraption for removing receptables from a Molex Microfit 3.0 plug using standard staplers

<u>Hobby & Makers</u> > <u>Tools</u>

Tags: molex microfit 11030043

A cheap and simple way to remove receptable terminals from a molex microfit 3.0 pin. Usually, you need a special tool from Molex, but a stapler does the job just fine. One side takes two staplers (DIN 24/6), one takes a single one. The single-stapler side works fine for me.

Printing

Printed in PLA with 0.12mm layer height and 3 walls. The staplers should fit quite snug, and the cap should press-fit with little resistance so it can be taken apart again.

Assembly

- 1. Place one stapler in the narrow path, and two (best if they're still connected) staplers in the deeper path.
- 2. Press-fit the cap on top.

3. Use pliers to cut off the legs flush on the corner

Usage

- 1. Push the wire deeper into the connector so the wings of the receptable aren't pressed against the plastic
- 2. Push the tool into the pin on **either side** of the pin, but between the plastic and the connector. If cut correctly, the stapler should fit into the pin with only 1mm of play
- 3. Wiggle the tool around to collapse the wing, sometimes rotating the tool helps too
- 4. Repeat the process on the other side too.
- 5. Pull out the wire

Model files



extractor-tool.step

base.stl

cap.stl

License **G**



This work is licensed under a Creative Commons (4.0 International License)

Attribution-NonCommercial

- ★ | Sharing without ATTRIBUTION
- ✓ | Remix Culture allowed
- ★ | Commercial Use
- ★ | Free Cultural Works
- ★ | Meets Open Definition