

Sony Dualshock 4 Controller



- A) X, Y Directional buttons
- B) Park toolhead (SHARE)
- C) Toggle recording of move points (Touch pad)
- D) not used (Speaker)
- E) Calibrate and goto home position (OPTIONS)
- F) Turn left/right and up/down
- G) Insert delay (R3)
- H) Power on/off and connect Bluetooth (PS)
- I) not used (Stereo headset jack)
- J) not used (Extension port)
- K) Insert point (L3)

Sony Dualshock 4 Controller



- A) Turn gripper clockwise (R1)
- B) Close gripper (R2)
- C) Light bar: blue->Bluetooth connected
- D) Turn gripper counter clockwise (L1)
- E) Open gripper (L2)
- F) USB port

Setup of Dualshock 4 Controller

- Press PS button and wait for lightbar to turn on
- Press Share and PS button and wait for blinking
- Pair with a PC
- Connect PS4 controller via USB to PC
- Run the SixaxisPairTool and PS4 controller to ESP32 Bluetooth MAC address