




tutorial.pro

lib


tutorial.sch





Working dir: G:\ProjectTemp\Current\Tutorial\1-Base  
Project: tutorial.pro





*Double click to open*
































Now lets copy this block and place it down a couple more times. You can click and drag a selection rectangle around everything, then right-click and select 'copy block'

Kicad is really messy with its screen redraws. You will quickly learn where the F3 key is to refresh the screen after each action. Why isn't it F5?

Pay attention to those keyboard shortcuts in the menus, they're really useful.











I probably should have made that change once, then just copied it the other 5 times. oh well. Now keyboard short-cut 'V' over the value will bring up the edit value box.


I changed it for each one,  
then drew wires in to connect to the pins.


Not everything connected.  
I'll put down some junctions  
to make sure... 


























025\_PCBnew5.jpg

