The Work Big IN72, IN74, IN76 uses the NEC IR protocol.

The customer code portion of the IR packet should use the hexadecimal value 0x4E87.

Function	Hex Code
Auto image	0x33
Blank	0x31
Bulb reset	0x18
Computer toggle	0x19
Contrast decrease	0x37
Contrast increase	0x36
Decrease brightness	0x07
Decrease volume	0x04
Down cursor	0x14
Effect	0x2B
Freeze	0x0E
Increase brightness	0x03
Increase volume	0x08
Keystone minus	0x21
Keystone plus	0x20
Left mouse	0x0C
Menu	0x02
Mute	0x29
Next slide	0x24
Overscan	0x35
Power off	0x39
Power on	0x3A
Power toggle	0x17
Preset toggle	0x2C
Previous slide	0x25
Resize	0x34
Resize 16x9	0x3C
Resize 4:3	0x3D
Resize native	0x3B
Right mouse	0x0B
Select	0x32
Source	0x10
Source 1	0x2D
Source 2	0x2E
Source 3	0x2F
Source 4	0x30
Up cursor	0x13
User preset 1	0x40
User preset 2	0x41
User preset 3	0x42
Video toggle	0x1A