Technical Documentation

**Product** IN5502 IN5502L IN5504 IN5504L
IN5532 IN5532L IN5534 IN5534L

**Title** IR Codes & Documentation

## Introduction:

IR (infrared) light can be used to send commands to and retrieve status information from many consumer devices. IR communication can be used for two-way data communication (mostly between computers and PDAs), though most display devices, including projectors, are configured to receive commands only. Commonly the IR capability of projectors is used in conjunction with the factory-provided remote control. However, if there are multiple devices that need control, you may wish to use a universal or learning remote.

Many universal remote controls can only control devices that the remote manufacturer has included in their table of pre-programmed codes. These types of universal remote controls aren't usually capable of controlling projectors and other less common equipment. A universal remote with a "Learning" function is suitable for use with projectors and other unique components (game consoles, media PCs & extenders, curtain/lighting controls, etc.). Many other programmable remotes are also able to work with projectors and other equipment.

If you need help setting up your universal "Learning" remote, please refer to the universal remote manufacturer's documentation.

The directions below are intended to help you set up a programmable remote, using the codes for your InFocus projector.

## Configuration:

- InFocus projectors use the NEC IR protocol.
- The customer code is used to identify the sender of the IR transmission. InFocus Corporation's customer code is hexadecimal value: 0x4E87
- Please note that the letter O is not used in hexadecimal, only zeros are used.

## Supported Commands:

| Key Name | Description | Hexadecimal |
|---|---|---|
| Menu | Toggles menu state up or down | 02h |
| Brightness Plus | Increases brightness | 03h |
| Volume Minus | Decreases volume | 04h |
| Brightness Minus | Decreases brightness | 07h |
| Volume Plus | Increases volume | 08h |
| Help | Displays help menu | 0Ah |
| Right Mouse Button | Sends right mouse click | 0Bh |
| Left Mouse Button | Sends left mouse click | 0Ch |
| Standby | Toggles standby state on or off | 0Dh |
| Freeze | Toggles freeze state on or off | 0Eh |
| Source Select | Selects next available source | 10h |
| Cursor Left | Moves menu cursor left | 11h |
| Cursor Right | Moves menu cursor right | 12h |
| Cursor Up | Moves menu cursor up | 13h |
| Cursor Down | Moves menu cursor down | 14h |
| Power | Toggles power state on or off | 17h |
| Computer Toggle | Selects next available computer source | 19h |
| Video Toggle | Selects next available video source | 1Ah |
| Keystone Plus | Increases keystone | 20h |
| Keystone Minus | Decreases keystone | 21h |
| Next Slide | Moves to next slide in powerpoint | 24h |
| Previous Slide | Moves to previous slide in powerpoint | 25h |
| Zoom Plus | Increases zoom ratio | 26h |
| Zoom Minus | Decreases zoom ratio | 27h |
| Zoom Toggle | Toggles zoom state on or off | 28h |
| Mute | Toggles audio mute state on or off | 29h |
| Custom | Performs programmed action of Custom Key | 2Bh |
| Presets | Toggles through available presets | 2Ch |
| Source1 | Selects programmed source | 2Dh |
| Source2 | Selects programmed source | 2Eh |
| Source3 | Selects programmed source | 2Fh |
| Source4 | Selects programmed source | 30h |
| Blank | Toggles state of blank screen on or off | 31h |
| Select | Selects current menu item | 32h |
| Auto Image | Activates automatic image re-acquisition | 33h |
| Resize | Toggles through available resize modes | 34h |
| Overscan | Toggles overscan state on or off | 35h |
| Contrast Plus | Increases contrast | 36h |

| | | |
|---|---|---|
| Contrast Minus | Decreases contrast | 37h |
| Discrete Power Off | Commands the system to power down | 39h |
| Discrete Power On | Commands the system to power up | 3Ah |
| Discrete Resize Native | Selects the Native aspect ratio | 3Bh |
| Discrete Resize 16:9 | Selects the 16:9 aspect ratio | 3Ch |
| Discrete Resize 4:3 | Selects the 4:3 aspect ratio | 3Dh |
| Discrete Resize Letterbox | Selects the Letterbox aspect ratio | 3Eh |
| Discrete Resize Natural Wide/Panorama | Selects the Natural Wide/Panorama aspect ratio | 3Fh |
| Discrete User Preset 1 | Selects the User Preset 1 | 40h |
| Discrete User Preset 2 | Selects the User Preset 2 (or selects ISF Day preset if projector supports that instead of user preset 2) | 41h |
| Discrete User Preset 3 | Selects the User Preset 3 (or selects ISF Night preset if projector supports that instead of user preset 3) | 42h |
| Discrete Blank Off | Turns off the blank screen | 43h |
| Discrete Blank On | Turns on the blank screen | 44h |
| Discrete Resize Auto | Selects the Auto aspect ratio | 45h |
| Discrete Resize 15:9 | Selects the 15:9 aspect ratio | 46h |
| Discrete Resize 16:10 | Selects the 16:10 aspect ratio | 47h |
| Focus Near | Motorized focus nearer | 48h |
| Focus Far | Motorized focus further | 49h |
| Zoom In | Motorized zoom in | 4Ah |
| Zoom Out | Motorized zoom out | 4Bh |
| Shift Left | Motorized lens shift move left | 4Ch |
| Shift Right | Motorized lens shift move right | 4Dh |
| Shift Up | Motorized lens shift move up | 4Eh |
| Shift Down | Motorized lens shift move down | 4Fh |