Keycode definitions for the X2

Use the table below to determine the keycodes that operate the functions listed in the first column.

Function	Code
Auto image	0x33
Blank	0x31
Bulb reset	0x18
Computer toggle	0x19
Contrast decrease	0x37
Contrast increase	0x36
Decrease brightness	0x07
Decrease volume	0x04
Down cursor	0x14
Effect	0x2B
Freeze	0x0E
Increase brightness	0x03
Increase volume	0x08
Keystone minus	0x21
Keystone plus	0x20
Left cursor	0x11
Left mouse	0x0C
Light	0x0F
Menu	0x02
Mute	0x29
Next slide	0x24
Overscan	0x35
Power toggle	0x17
Preset toggle	0x2C
Previous slide	0x25
Program flash	0x2A
Resize	0x34
Right cursor	0x12
Right mouse	0x0B
Select	0x32
Source	0x10
Source 1	0x2D
Source 2	0x2E
Source 3	0x2F
Source 4	0x30
Standby	0x0D
Up cursor	0x13
Video toggle	0x1A
Zoom decrease	0x27
Zoom increase	0x26
Zoom toggle	0x28