standBack Sur-

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Back Sur+

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Cancel

0000 006c 0000 0026 0159 00ac 0016 0015 0014 0041 0017 0015 0014 0016 0016 0016 0016 0015 0014 0016 0016 0015 0017 003f 0015 0016 0017 003f 0016 0041 0014 0041 0017 003f 0016 0041 0014 0041 0017 003f 0015 0016 0017 0015 0014 0041 0017 003f 0015 0016 0017 003f 0015 0016 0017 0015 0014 0041 0017 003f 0015 0016 0017 0014 0015 0041 0016 0015 0015 0041 0016 05f5 015a 0055 0014 0e5c 015a 0055 0015 0e5c

Center –

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Center +

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Emotiva UMC-1 Metal Remote Codes – rev 1/25/11

Channel Down

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016
0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015
0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016
0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015
0016 0040 0016 05E7 0157 0055 0016 0E3B

Channel Up

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016
0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015
0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016
0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015
0016 0040 0016 05E7 0157 0055 0016 0E3B

Dim

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016
0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015
0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016
0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015
0016 0040 0016 05E7 0157 0055 0016 0E3B

Dolby Volume

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016
0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015
0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016
0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040
0016 0040 0016 05E7 0157 0055 0016 0E3B

Down Arrow

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016
0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015
0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016
0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040
0016 0040 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Emotiva UMC-1 Metal Remote Codes – rev 1/25/11

Enter

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Info

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Left

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Menu

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Mute

0000 006d 0022 0002 0156 00a9 0016 0015 0015 0016 0015 0015 0016 0015 0015 0016 0014 0040 0015 0016 0015 0015 0016 0040 0015 003f 0015 0040 0016 0040 0015 0040 0015 0015 0015 0040 0015 0016 0015 0040 0015 0016 0014 0016 0015 0015 0015 0016 0015 0015 0016 0015 0015 0016 0015 0015 0015 0040 0015 0040 0015 0040 0016 003f 0015 0040 0015 0040 0016 003f 0015 0610 0155 0055 0015 0e33

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Emotiva UMC-1 Metal Remote Codes – rev 1/25/11

Power Off

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Power On

0000 006d 0022 0002 0155 00aa 0015 0015 0015 0016 0015 0015 0016 0015 0015 0015 0015 0040 0015 0016 0015 0015 0016 003f 0015 0040 0015 0040 0015 0040 0015 0040 0015 0016 0014 0040 0015 0016 0015 0015 0016 0015 0014 0016 0015 0015 0016 0015 0015 0016 0015 0015 0015 0015 0015 0040 0016 0040 0015 003f 0015 0040 0016 003f 0015 0040 0015 0040 0016 003f 0015 060d 0155 0055 0015 0e2e

Recall

0000 006d 0022 0002 0155 00ab 0015 0016 0014 0041 0015 0016 0014 0016 0015 0016 0014 0016 0014 0016 0015 0016 0015 0040 0016 0015 0015 0040 0016 0040 0014 0041 0015 003f 0016 0040 0015 0040 0015 0040 0015 0016 0015 0016 0015 0040 0015 0040 0015 0015 0015 0016 0014 0016 0016 0015 0015 0040 0015 0041 0015 0015 0016 0015 0015 0040 0015 0040 0014 0041 0015 05e7 0155 0056 0015 0e38

Right Arrow

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Source 1 - Tuner

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Source 2 – ***UMC Source 1 - DVD***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Source 3 – ***UMC Source 2 - Cable***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Source 4 – ***UMC Source 3 - SAT***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Source 5 – ***UMC Source 4 - VCR***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Source 6 – ***UMC Source 5- AUX1***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Source 7 – ***UMC Source 6***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Source 8 – ***UMC Source 7***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Source 9 – ***UMC Source 8***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Source 10 – ***UMC Source 9 – Aux 5***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Source 11 – ***UMC Source 10 – Aux 6***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Source 12 – ***UMC Source 11***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Source 13 – ***UMC Source 12***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Source 14 – ***UMC Source 13***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Source 15 – ***UMC Source 14 – AUX 10***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Source 16 – ***UMC Source 15***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Source 17 – ***UMC Source 16 – Aux 12***

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 05E7 0157 0055 0016 0E3B

Status

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Sub –

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Sub +

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Surround –

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Emotiva UMC-1 Metal Remote Codes – rev 1/25/11

Surround +

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Toggle Input

0000 006d 0022 0002 0154 00ab 0015 0015 0015 0016 0015 0016 0014 0016 0015 0016 0015 0040 0015 0015 0015 0016 0014 0041 0015 0040 0015 0040 0014 0041 0015 0040 0015 0016 0015 003f 0015 0016 0015 0040 0015 0016 0015 0040 0015 0040 0014 0016 0015 0016 0015 0016 0014 0016 0015 0016 0014 0040 0015 0016 0015 0016 0014 0041 0015 003f 0015 0041 0014 0041 0015 0610 0154 0056 0015 0e33

Up Arrow

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Volume –

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Volume +

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Emotiva UMC-1 Metal Remote Codes – rev 1/25/11

Zone 2 Band

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Zone 2 Cannel –

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Zone 2 Channel +

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Zone 2 Input

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Zone 2 Power

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.

Zone 2 Vol –

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Zone 2 Vol +

0000 006D 0022 0002 0157 00AB 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0040 0016 0015 0016 0015 0016 0040 0016 0040 0016 0040 0016 0040 0016 0040 0016 0015 0016 0040 0016 0015 0016 0015 0016 0015 0016 0040 0016 0040 0016 0015 0016 0015 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 0040 0016 0015 0016 0040 0016 05E7 0157 0055 0016 0E3B

Here are the current complimentary IR codes, in hex format, for your use in programmable remotes that accept hex codes. We do not guarantee the accuracy of these codes nor their use in your particular remote. These are offered purely as a complimentary feature of the Emotiva UMC product family. Keep in mind you may have issues with repeat counts, timings, durations, emitter placement, etc. as you program your remote control system of choice. We offer no support for any remotes or IR teaching/learning processes other than factory UMC remote.