The Work Big IN72, IN74, IN76 uses the NEC IR protocol.

The customer code portion of the IR packet should use the hexadecimal value 0x4E87.

Remote control commands		
Key Name	**Hex Code**	**Description**
Menu	0x02	Toggles menu state up or down
Brightness Plus	0x03	Increases brightness
Brightness Minus	0x07	Decreases brightness
Freeze	0x0E	Toggles freeze state on or off
Source Select	0x10	Selects next available source
Cursor Up	0x13	Moves menu cursor up
Cursor Down	0x14	Moves menu cursor down
Power	0x17	Toggles power state on or off
Keystone Plus	0x20	Increases keystone
Keystone Minus	0x21	Decreases keystone
Presets	0x2C	Toggles through available presets
Source1	0x2D	Selects programmed source
Source2	0x2E	Selects programmed source
Source3	0x2F	Selects programmed source
Source4	0x30	Selects programmed source
Blank	0x31	Toggles state of blank screen on or off
Select	0x32	Selects current menu item
Auto Image	0x33	Activates automatic image re-acquisition
Resize	0x34	Toggles through available resize modes
Overscan	0x35	Toggles through available overscan states
Contrast Plus	0x36	Increases contrast
Contrast Minus	0x37	Decreases contrast
Discrete Power OFF	0x39	Turns power off.
Discrete Power ON	0x3A	Turns power on.
Native Resize	0x3B	Selects Native Resize.
16:9 Resize	0x3C	Selects 16:9 Resize.
4:3 Resize	0x3D	Selects 4:3 Resize.
Letterbox Resize	0x3E	Selects Letterbox Resize.
Natural Wide Resize	0x3F	Selects Natural Wide Resize.
User Preset 1	0x40	Selects User Preset 1
User Preset 2	0x41	Selects User Preset 2
User Preset 3	0x42	Selects User Preset 3